
Order No: PAPAMY1312011CE

# Service Manual Air Conditioner



Indoor Unit CS-RE18QKE CS-RE24QKE

CU-RE18QKE CU-RE24QKE

Outdoor Unit

Destination Europe E.Europe L.America Turkey

# WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

# IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by  $\triangle$  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

# A PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.



© Panasonic Corporation 2013.

# **TABLE OF CONTENTS**

1.	Safe	Safety Precautions3						
2.	Spe	Specifications5						
3.	Fea	Features8						
4.	Loc	ation of Controls and Components	9					
2	4.1 4.2 4.3	Indoor Unit Outdoor Unit Remote Control	9					
5.	Dim	ensions	.10					
-	5.1 5.2	Indoor Unit & Remote Control Outdoor Unit						
6.	Ref	rigeration Cycle Diagram	.13					
7.	Blo	ck Diagram	.15					
	7.1 7.2	CS-RE18QKE CU-RE18QKE CS-RE24QKE CU-RE24QKE						
8.	Wiri	ng Connection Diagram	.17					
-	3.1 3.2	Indoor Unit Outdoor Unit						
9.	Elec	ctronic Circuit Diagram	.20					
	).1 ).2	Indoor Unit Outdoor Unit	-					
		ited Circuit Board						
	10.1	Indoor Unit						
	0.2	Outdoor Unit	.24					
11.	Inst	allation Instruction	.27					
1	1.1  1.2  1.3	Select the Best Location Indoor Unit Outdoor Unit	.28					
1	1.2  1.3	Indoor Unit	.28 .33					
1 12. 1 1 1 1 1 1	11.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5	Indoor Unit Outdoor Unit eration and Control Basic Function Airflow Direction ON Timer Control OFF Timer Control Auto Restart Control	.28 .33 .36 .38 .40 .40 .40					
1 12. 1 1 1 1 1 1	11.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5	Indoor Unit Outdoor Unit eration and Control Basic Function Airflow Direction ON Timer Control OFF Timer Control Auto Restart Control tection Control	.28 .33 .36 .36 .38 .40 .40 .40 .40 .40					
1 12. 1 1 1 1 1 1 3. 1 3. 1 1 3.	11.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5	Indoor Unit Outdoor Unit eration and Control Basic Function Airflow Direction ON Timer Control OFF Timer Control Auto Restart Control	.28 .33 .36 .36 .40 .40 .40 .40 .40 .41 .41					
1 1 1 1 1 1 1 1 1 3 1 3 1 1 1 1	1.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5 <b>Pro</b> 3.1 3.2 3.2	Indoor Unit Outdoor Unit eration and Control Basic Function Airflow Direction ON Timer Control OFF Timer Control Auto Restart Control tection Control For All Operations Protection Control For Cooling & Soft Dry Operation	.28 .33 .36 .36 .40 .40 .40 .40 .40 .41 .41 .43 .44					
1 12. 1 1 1 1 1 1 3 1 3 1 4 1 4 4. 1 1 4. 1	1.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5 <b>Pro</b> 3.1 3.2 3.2	Indoor Unit Outdoor Unit Basic Function Airflow Direction ON Timer Control OFF Timer Control Auto Restart Control Frotection Control For All Operations Protection Control For Cooling & Soft Dry Operation Protection Control For Heating Operation .	.28 .33 .36 .38 .40 .40 .40 .40 .41 .41 .41 .43 .44 .45					
1 12. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5 13.1 3.2 3.3 3.3 <b>Ser</b> 4.1 4.2	Indoor Unit Outdoor Unit Pration and Control Basic Function Airflow Direction ON Timer Control OFF Timer Control OFF Timer Control Auto Restart Control Auto Restart Control Protection Control For All Operations Protection Control For All Operations Protection Control For Cooling & Soft Dry Operation Protection Control For Heating Operation . Vicing Mode Auto OFF/ON Button	.28 .33 .36 .36 .38 .40 .40 .40 .40 .40 .41 .41 .43 .44 .45 .45					
1 12. 1 1 1 1 1 1 1 1 1 1 1 1 1 5. 1	1.2 11.3 <b>Ope</b> 2.1 2.2 2.3 2.4 2.5 13.1 3.2 3.3 3.3 <b>Ser</b> 4.1 4.2	Indoor UnitOutdoor UnitOutdoor UnitOutdoor UnitOutdoor UnitOn and ControlON Timer ControlON Timer ControlOFF Control For All OperationsProtection Control For Heating OperationProtection Control For Heating Control For Heati	.28 .33 .36 .38 .40 .40 .40 .40 .40 .40 .41 .43 .44 .43 .44 .45 .46 .45 .46 .47 ne					

# 16. Disassembly and Assembly Instructions ..... 80

16.1 16.2	Fan and Indoor Fan Motor Removal Procedures Outdoor Electronic Controller Removal	
	Procedure	85
17. Tec	hnical Data	87
17.1 17.2	Cool Mode Performance Data Heat Mode Performance Data	
18. Serv	vice Data	89
18.1	Cool Mode Outdoor Air Temperature Characteristic	89
18.2	Heat Mode Outdoor Air Temperature Characteristic	91
18.3	Piping Length Correction Factor	
19. Exp	loded View and Replacement Parts List.	94
19.1 19.2	Indoor Unit Outdoor Unit	

# **1. Safety Precautions**

- Read the following "SAFETY PRECAUTIONS" carefully before perform any servicing.
- Electrical work must be installed or serviced by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each
  indication used is as below. Incorrect installation or servicing due to ignoring of the instruction will cause harm or damage,
  and the seriousness is classified by the following indications.

A WARNING This indication shows the possibility of causing death or serious injury.			
▲ CAUTION This indication shows the possibility of causing injury or damage to properties.			

• The items to be followed are classified by the symbols:

$\otimes$	This symbol denotes item that is PROHIBITED from doing.

Carry out test run to confirm that no abnormality occurs after the servicing. Then, explain to user the operation, care and
maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

1.	Do not modify the machine, part, material during repairing service.
2.	If wiring unit is supplied as repairing part, do not repair or connect the wire even only partial wire break. Exchange the whole wiring unit.
3.	Do not wrench the fasten terminal. Pull it out or insert it straightly.
4.	Engage dealer or specialist for installation and servicing. If installation of servicing done by the user is defective, it will cause water leakage, electrical shock or fire.
5.	Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electric shock or fire.
6.	Use the attached accessories parts and specified parts for installation and servicing. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock.
7.	Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
8.	For electrical work, follow the local national wiring standard, regulation and the installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.
9.	This equipment is strongly recommended to install with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case equipment breakdown or insulation breakdown.
10.	Do not use joint cable for indoor / outdoor connection cable. Use the specified Indoor/Outdoor connection cable, refer to installation instruction <b>CONNECT THE CABLE TO THE INDOOR UNIT</b> and connect tightly for indoor / outdoor connection. Clamp the cable so that no external force will be acted on the terminal. If connecting or fixing is not perfect, it will cause heat up or fire at the connection.
11.	Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause heat-up or fire at the connection point of terminal, fire or electrical shock.
12.	When install or relocate air conditioner, do not let any substance other than the specified refrigerant, eg. air etc. mix into refrigeration cycle (piping). (Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc.).
13.	Do not install outdoor unit near handrail of veranda. When installing air-conditioner unit at veranda of high rise building, child may climb up to outdoor unit and cross over the handrail and causing accident.
14.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electric shock in case equipment breakdown or insulation breakdown.
15.	Keep away from small children, the thin film may cling to nose and mouth and prevent breathing.
16.	Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.
17.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage.
18.	<ul> <li>For R410A model, use piping, flare nut and tools which is specified for R410A refrigerant. Using of existing (R22) piping, flare nut and tools may cause abnormally high pressure in the refrigerant cycle (piping), and possibly result in explosion and injury.</li> <li>Thickness or copper pipes used with R410A must be more than 0.8 mm. Never use copper pipes thinner than 0.8 mm.</li> <li>It is desirable that the amount of residual oil less than 40 mg/10 m.</li> </ul>
19.	During installation, install the refrigerant piping properly before run the compressor. (Operation of compressor without fixing refrigeration piping and valves at opened condition will caused suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc).

20.	During pump down operation, stop the compressor before remove the refrigeration piping. (Removal of compressor while compressor is operating and valves are opened will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury et
21.	After completion of installation or service, confirm there is no leakage or refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire.
22.	Ventilate if there is refrigerant gas leakage during operation. It may cause toxic gas when refrigerant contacts with fire.
23.	Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury.
24.	Must not use other parts except original parts described in catalog and manual.
25.	Using of refrigerant other than the specified type may cause product damage, burst and injury etc.

1.	Do not install the unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	$\bigcirc$
2.	Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage furniture.	the
3.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flar break and cause refrigerant gas leakage.	e may
4.	Do not touch outdoor unit air inlet and aluminium fin. It may cause injury.	$\bigcirc$
5.	Select an installation location which is easy for maintenance.	
6.	Pb free solder has a higher melting point than standard solder; typically the melting point is 50°F – 70°F (30°C – 40°C) higher. Please use a high temperature solder iron. In case of the soldering iron with temperature control, please set it to 700 ± 20°F (370 ± Pb free solder will tend to splash when heated too high (about 1100°F / 600°C).	10°C).
7.	<ul> <li>Power supply connection to the room air conditioner.</li> <li>Use power supply cord 3 × 1.5 mm² (1.0 ~ 1.75HP), 3 × 2.5 mm² (2.0 ~ 2.5HP) type designation 60245 IEC 57 or heavier cord.</li> <li>Connect the power supply cord of the air conditioner to the mains using one of the following method.</li> <li>Power supply point should be in easily accessible place for power disconnection in case of emergency.</li> <li>In some countries, permanent connection of this air conditioner to the power supply is prohibited.</li> <li>1) Power supply connection to the receptacle using power plug.</li> <li>Use an approved 15/16A (1.0 ~ 1.75HP), 16A (2.0HP), 20A (2.5HP) power plug with earth pin for the connection to the socket.</li> <li>2) Power supply connection to a circuit breaker for the permanent connection.</li> <li>Use an approved 16A (1.0 ~ 2.0HP), 20A (2.5HP) circuit breaker for the permanent connection. It must be a double pole switch with a minimum 3.0 mm contact gap.</li> </ul>	
8.	Do not release refrigerant during piping work for installation, servicing, reinstallation and during repairing a refrigerant parts. Take care of the liquid refrigerant, it may cause frostbite.	$\bigcirc$
9.	Installation or servicing work: It may need two people to carry out the installation or servicing work.	
10.	Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.	$\bigcirc$
11.	Do not sit or step on the unit, you may fall down accidentally.	$\bigcirc$
12.	Do not touch the sharp aluminium fins or edges of metal parts. If you are required to handle sharp parts during installation or servicing, please wear hand glove. Sharp parts may cause injury.	$\bigcirc$

# 2. Specifications

Model		Model	Indoor		CS-RE18QKE			CS-RE24QKE								
Outdoor			CU-RE18QKE			CU-RE24QKE										
Performance Test Condition			EUROVENT			EUROVENT										
	Pov	ver Supply	Phase, Hz		Single, 50		Single, 50									
	100		V		230			230								
				Min.	Mid.	Max.	Min.	Mid.	Max.							
			kW	0.98	5.00	6.00	0.98	6.80	8.10							
	Capacity		BTU/h	3340	17100	20500	3340	23200	27600							
			Kcal/h	840	4300	5160	840	5850	6970							
	Ru	nning Current	A	_	6.6	_	_	9.6	-							
	I	nput Power	W	280	1.47k	2.03k	380	2.10k	2.67k							
	Annu	al Consumption	kWh	_	735	_	_	1050	-							
			W/W	3.50	3.40	2.96	2.58	3.24	3.03							
		EER	BTU/hW	11.93	11.63	10.10	8.79	11.05	10.34							
bu			Kcal/hW	3.00	2.93	2.54	2.21	2.79	2.61							
Cooling		Pdesign	kW		5.0			6.8								
		SEER	(W/W)		6.7			6.0								
E	ĒrP	Annual Consumption	kWh		261			397								
		Class			A++		A+									
	Ρ	ower Factor	%	-	97	-	-	95	-							
	Indo	or Noise (H / L)	dB-A		44 / 37 47 / 38											
	muo		Power Level dB	60 63			63									
	Outd	oor Noise (H / L)	dB-A	47			52									
	Outuo		Power Level dB	61 66			66									
	Capacity		kW	0.98	5.80	8.00	0.98	8.60	9.90							
			BTU/h	3340	19800	27300	3340	29300	33800							
			Kcal/h	840	4990	6880	840	7400	8510							
	Ru	nning Current	A	-	6.9	-	-	11.7	-							
	I	nput Power	W	340	1.54k	2.60k	450	2.61k	3.13k							
			W/W	2.88	3.77	3.08	2.18	3.30	3.16							
		COP	BTU/hW	9.82	12.86	10.50	7.42	11.23	10.80							
			Kcal/hW	2.47	3.24	2.65	1.87	2.84	2.72							
Heating		Pdesign	kW		4.4		5.5									
He	ļ	Tbivalent	°C		-10		-10									
E	ΓP	SCOP	(W/W)		4.1		3.8									
									Annual Consumption	kWh		1502			2026	
		Class			A+			А								
	Power Factor		%	-	97	-	-	97	-							
	Indo	or Noise (H / L)	dB-A		44 / 37		47 / 38									
			Power Level dB		60			63								
	Outdo	oor Noise (H / L)		47				52								
			Power Level dB		61		66									
		p. : Capacity (kW) /		5.80 / 2.35k / 2.47			7.17 / 2.77k / 2.59									
Extr L			) / I.Power (W) / COP	2	.98 / 2.41k / 2.0	17	6	.13 / 2.75k / 2.2	23							
	Max	Current (A) / Max In			11.4 / 2.60k			14.5 / 3.13k								
		Starting Currer	nt (A)		6.9			11.7								

				Indoor	CS-RE18QKE	CS-RE24QKE
Model		Outdoor	CU-RE18QKE	CU-RE24QKE		
Туре			Hermetic Motor (Rotary)	Hermetic Motor (Rotary)		
Со	Compressor Motor Type			Brushless (4-poles)	Brushless (4-poles)	
		Output Power		W	900	1.7k
	Туре				Cross-Flow Fan	Cross-Flow Fan
	Material				ASG20K1	ASG20K1
	Motor Type				DC / Transistor (8 poles)	DC / Transistor (8 poles)
	In	put Pow	er	W	94.8	94.8
an	Οι	utput Pov	wer	W	40	40
Indoor Fan			Cool	rpm	960	1000
opu		Lo	Heat	rpm	1070	1090
			Cool	rpm	1080	1230
	Speed	Me	Heat	rpm	1190	1280
			Cool	rpm	1200	1460
		Hi	Heat	rpm	1310	1480
		Туре	1		Propeller Fan	Propeller Fan
		Materia			PP	PP
Fan	N	lotor Typ	be		DC (8-poles)	DC (8-poles)
Outdoor Fan	In	put Pow	er	W	_	_
Outd	Οι	utput Pov	wer	W	40	60
Ŭ	0		Cool	rpm	640	660
	Speed	Hi	Heat rpm		640	640
	Moisture Removal		L/h (Pt/h)	2.8 (5.9)	3.9 (8.2)	
			Cool	m <sup>3</sup> /min (ft <sup>3</sup> /min)	12.65 (447)	12.08 (427)
		Lo	Heat	m <sup>3</sup> /min (ft <sup>3</sup> /min)	14.25 (503)	13.34 (471)
	Indoor		Cool	m <sup>3</sup> /min (ft <sup>3</sup> /min)	14.45 (510)	15.30 (540)
	Airflow	Me	Heat	m <sup>3</sup> /min (ft <sup>3</sup> /min)	16.05 (567)	16.07 (568)
			Cool	m <sup>3</sup> /min (ft <sup>3</sup> /min)	16.30 (575)	18.40 (650)
		Hi	Heat	m <sup>3</sup> /min (ft <sup>3</sup> /min) 17.90 (630)		19.50 (690)
(	Dutdoor	Hi Cool m <sup>3</sup> /min (ft <sup>3</sup> /min) 39.2 (138		39.2 (1385)	50.2 (1770)	
	Airflow		Heat	m³/min (ft³/min)	37.9 (1340)	50.2 (1770)
		Potrigorant ()II			Expansion Valve	Expansion Valve
	frigeration Cycle			cm <sup>3</sup>	FV50S (450)	FV50S (800)
	- <b>)</b>	Refrige	erant Type	g (oz)	R410A, 1.22k (43.1)	R410A, 1.80k (63.5)
		Height	(I/D / O/D)	mm (inch)	290 (11-7/16) / 695 (27-3/8)	290 (11-7/16) / 795 (31-5/16)
Di	mension	Width (	I/D / O/D)	mm (inch)	1070 (42-5/32) / 875 (34-15/32)	1070 (42-5/32) / 875 (34-15/32)
		Depth	(I/D / O/D)	mm (inch)	240 (9-15/32) / 320 (12-5/8)	240 (9-15/32) / 320 (12-5/8)
1	Weight	Net (I	/D / O/D)	kg (lb)	12 (26) / 46 (101)	12 (26) / 67 (148)
	Pipe Diam	neter (Lio	quid / Gas)	mm (inch)	6.35 (1/4) / 12.70 (1/2)	6.35 (1/4) / 15.88 (5/8)
	Sta	ndard le	ngth	m (ft)	5.0 (16.4)	5.0 (16.4)
Piping	Length r	ange (m	in – max)	m (ft)	3 (9.8) ~ 20 (65.6)	3 (9.8) ~ 30 (98.4)
Pip	I/D & O/	D Height	different	m (ft)	15.0 (49.2)	20 (65.6)
	Additio	nal Gas	Amount	g/m (oz/ft)	20 (0.2)	30 (0.3)
	Length f	or Additi	onal Gas	m (ft)	7.5 (24.6)	10 (32.8)
Dre	ain Hose -	Inner [	Diameter	mm	16.7	16.7
אוט		Le	ngth	mm	650	650

Model		Indoor	CS-RE1	8QKE	CS-RE2	4QKE
		Outdoor	CU-RE1	8QKE	CU-RE24QKE	
	Fin Material		Aluminium (Pre Coat)		Aluminium (Pre Coat)	
Indoor Heat	Fin Type		Slit Fin		Slit Fin	
Exchanger	Row × Stage × FPI		2 × 15 × 17		2 × 15 × 21	
	Size (W × H × L)	mm	810 × 315	5 × 25.4	810 × 315 × 25.4	
	Fin Material		Aluminium (	(Pre Coat)	Aluminium (	Pre Coat)
Outdoor Heat	Fin Type		Corrugat	ted Fin	Corrugat	ted Fin
Exchanger	Row × Stage × FPI		2 × 31	× 19	2 × 30	× 19
	Size (W × H × L)	mm	36.4 × 651 ×	854.5:824.5	38.1 × 762 ×	895.8:865.8
A in Filter	Material		Polyprop	pelene	Polypropelene	
Air Filter	Туре		One-touch		One-touch	
Pov	wer Supply		Indoor		Indoor	
Power	Supply Cord	А	Nil		Ni	l
Tł	nermostat		Nil		Nil	
Prote	ction Device		Electronic Contol		Electronic Contol	
			Dry Bulb	Wet Bulb	Dry Bulb	Wet Bulb
	Que a line au	Maximum °C	32	23	32	23
Indoor	Cooling	Minimum °C	16	11	16	11
Operation Range		Maximum °C	30	_	30	_
	Heating	Minimum °C	16	_	16	_
	Cooling	Maximum °C	43	26	43	26
Outdoor	Cooling	Minimum °C	-10	_	-10	_
Operation Range		Maximum °C	24	18	24	18
	Heating	Minimum °C	-15	-16	-15	-16

Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and outdoor air 1.

Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and out temperature of 35°C Dry Bulb (95°F Dry Bulb), 24°C Wet Bulb (75.2°F Wet Bulb) Heating capacities are based on indoor temperature of 20°C Dry Bulb (68°F Dry Bulb) and outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) Heating low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor 2/1°C. Heating extreme low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor -7/-8°C. Standby power consumption ≤2.0w (when switched OFF by remote control, except under self protection control). Specifications are subjected to change without prior notice for further improvement. 2.

3.

4. 5.

6.

# 3. Features

### Inverter Technology

- Wider output range
- Energy saving
- More precise temperature control

#### • Environment Protection

• Non-ozone depletion substances refrigerant (R410A)

#### Long Installation Piping

- o CS/CU-RE18QKE, long piping up to 20 meter
- CS/CU-RE24QKE, long piping up to 30 meter

#### • Easy to use remote control

#### • Quality Improvement


- o Random auto restart after power failure for safety restart operation
- o Gas leakage protection
- Prevent compressor reverse cycle
- Inner protector to protect compressor
- Noise prevention during soft dry operation

#### • Serviceability Improvement


• Breakdown Self Diagnosis function

# 4. Location of Controls and Components


# 4.1 Indoor Unit



# 4.2 Outdoor Unit




# 4.3 Remote Control





# 5. Dimensions


#### 5.1 Indoor Unit & Remote Control

<Top View>












<Bottom View>








<Back View>






<Remote Control Holder>


Relative position between the indoor unit and the installation plate <Front View>






# 5.2 Outdoor Unit

# 5.2.1 CU-RE18QKE




# 5.2.2 CU-RE24QKE



Unit : mm

# 6. Refrigeration Cycle Diagram


# 6.1.1 CS-RE18QKE CU-RE18QKE



---► HEATING




OUTDOOR




--- HEATING

# 7. Block Diagram

# 7.1 CS-RE18QKE CU-RE18QKE




# 7.2 CS-RE24QKE CU-RE24QKE




# 8. Wiring Connection Diagram

# 8.1 Indoor Unit



# 8.2 Outdoor Unit


### 8.2.1 CU-RE18QKE



MODEL	CU-RE18QKE
CONNECTION	5RD132XBA21
U-V	1.897 Ω
U-W	1.882 Ω
V-W	1.907 Ω

Note: Resistance at 20°C of ambient temperature.

# 8.2.2 CU-RE24QKE




Resistance of Compressor Windings

MODEL	CU-RE24QKE			
CONNECTION	5KD240XAF21			
U-V	0.720 Ω			
U-W	0.726 Ω			
V-W	0.708 Ω			

Note: Resistance at 20°C of ambient temperature.


# 9. Electronic Circuit Diagram

# 9.1 Indoor Unit




# 9.2 Outdoor Unit

### 9.2.1 CU-RE18QKE




# 9.2.2 CU-RE24QKE



# **10. Printed Circuit Board**


# 10.1 Indoor Unit

# 10.1.1 Main Printed Circuit Board



JP1 (Random Auto Restart enable/disable)


# 10.1.2 Indicator Printed Circuit Board




# 10.2 Outdoor Unit

# 10.2.1 Main Printed Circuit Board

# 10.2.1.1 CU-RE18QKE




# 10.2.1.2 CU-RE24QKE



# 10.2.2 Noise Filter Printed Circuit Board

# 10.2.2.1 CU-RE24QKE



# 11. Installation Instruction

# 11.1 Select the Best Location

# 11.1.1 Indoor Unit

- Do not install the unit in excessive oil fume area such as kitchen, workshop and etc.
- There should not be any heat source or steam near the unit.
- There should not be any obstacles blocking the air circulation.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near the door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 2.5 m.

# 11.1.2 Outdoor Unit


- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over the [piping length for additional gas], additional refrigerant should be added as shown in the table.

	Horse Power (HP)	Piping size		Std.	Max.	Min. Piping	Max. Piping	Additional	Piping Length		
Model		Gas	Liquid	Length (m)	Elevation (m)	Length (m)	Length (m)	Refrigerant (g/m)	for add. gas (m)		
RE9***,UE9***,YE9***	1.0HP	(3/8")			15	3	15	20	7.5		
RE12***,UE12***,YE12***	1.5HP		(3/8")	(3/8")		25mm	15	3	15	20	7.5
RE15***	1.75HP				6.35mm		15	3	15	20	7.5
UE18***	2.0HP		(1/4")	5	15	3	15	20	7.5		
RE18***	2.005	(112)			15	3	20	20	7.5		
RE24***	2.5HP	15.88mm (5/8")			20	3	30	30	10		

Example: For RE9\*\*\*

If the unit is installed at 10 m distance, the quantity of additional refrigerant should be 50 g .... (10-7.5) m × 20 g/m = 50 g.

# 11.1.3 Indoor/Outdoor Unit Installation Diagram




• This illustration is for explanation purposes only. The indoor unit will actually face a different way

# 11.2 Indoor Unit

# 11.2.1 How to Fix Installation Plate

The mounting wall shall be strong and solid enough to prevent if from the vibration.



Model	Dimension							
Model	0	0	3	4	5	6		
RE9***,UE9***,YE9*** RE12***,UE12***,YE12*** RE15***	490 mm	82 mm	439 mm	432 mm	43 mm	95 mm		
RE18***,UE18*** RE24***	590 mm	82 mm	539 mm	532 mm	169 mm	219 mm		

The center of installation plate should be at more than ① at right and left of the wall.

The distance from installation plate edge to ceiling should more than O.

From installation plate center to unit's left side is ③.

From installation plate center to unit's right side is ④.

- B : For left side piping, piping connection for liquid should be about (5) from this line.
  - : For left side piping, piping connection for gas should be about (6) from this line.
- 1 Mount the installation plate on the wall with 5 screws or more (at least 5 screws).
  - (If mounting the unit on the concrete wall, consider using anchor bolts.)
  - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
- 2 Drill the piping plate hole with ø70 mm hole-core drill.
  - Line according to the left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely 128 mm for left and right hole respectively.
  - Drill the piping hole at either the right or the left and the hole should be slightly slanting to the outdoor side.


### 11.2.2 To Drill a Hole in the Wall and Install a Sleeve of Piping

- 1 Insert the piping sleeve to the hole.
- 2 Fix the bushing to the sleeve.
- 3 Cut the sleeve until it extrudes about 15 mm from the wall.

### 


• When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.

4 Finish by sealing the sleeve with putty or caulking compound at the final stage.



#### 11.2.3 Indoor Unit Installation

- Do not turn over the unit without it's shock absorber during pull out the piping. It may cause intake grille damage.
  Use shock absorber during pull out the piping to protect the intake grille from damage.



#### 11.2.3.1 For the right rear piping

Step-1	Pull out the Indoor piping
+	
Step-2	Install the Indoor Unit
-	
Step-3	Secure the Indoor Unit
-	
Step-4	Insert the power supply cord and connection cable
	Insert the cables from bottom of the unit through


the control board hole until terminal board area.


#### 11.2.3.2 For the right and right bottom piping

	1-13
Step-1	Pull out the Indoor piping
-	
Step-2	Install the Indoor Unit
-	
Step-3	Insert the power supply cord and connection cable
₽	Insert the cables from bottom of the unit through the control board hole until terminal board area.
Step-4	Secure the Indoor Unit


#### 11.2.3.3 For the embedded piping

	11 5
Step-1	Replace the drain hose
Step-2	Bend the embedded piping
₽	• Use a spring bender or equivalent to bend the piping so that the piping is not crushed.
Step-3	Pull the connection cable into Indoor Unit
₽	The power supply cord and indoor unit and outdoor unit connection cable can be connected without removing the front grille.
Step-4	Cut and flare the embedded piping
•	<ul> <li>When determining the dimensions of the piping, slide the unit all the way to the left on the installation plate.</li> <li>Refer to the section "Cutting and flaring the piping".</li> </ul>
Step-5	Install the Indoor Unit
Step-6	Connect the piping
₽	Please refer to "Connecting the piping" column in outdoor unit section. (Below steps are done after connecting the outdoor piping and gas-leakage confirmation.)
Step-7	Insulate and finish the piping
•	<ul> <li>Please refer to "Insulation of piping connection" column as mentioned in indoor/outdoor unit installation.</li> </ul>
Step-8	Secure the Indoor Unit





(This can be used for left rear piping and left bottom piping also.)




# 11.2.4 Connect the Cable to the Indoor Unit


The power supply cord, indoor and outdoor unit connection cable can be connected without removing the front grille.

- 1 Install the indoor unit on the installing holder that mounted on the wall.
- 2 Open the front panel and grille door by loosening the screw.
- 3 Cable connection to the power supply through Isolating Devices (Disconnecting means).
  - Connect approved type polychloroprene sheathed power supply cord 3 × 1.5 mm<sup>2</sup> (1.0 ~ 1.75HP), 3 × 2.5 mm<sup>2</sup> (2.0 ~ 2.5HP) type designation 60245 IEC 57 or heavier cord to the terminal board, and connect the others end of the cord to Isolating Devices (Disconnecting means).
  - Do not use joint power supply cord. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.
  - In unavoidable case, joining of power supply cord between isolating devices and terminal board of air conditioner shall be done by using approved socket and plug with earth pin rated 15/16/20A. Wiring work to both socket and plug must follow to national wiring standard.
- 4 Bind all the power supply cord lead wire with tape and route the power supply cord via the left escapement.
- 5 Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 × 1.5 mm<sup>2</sup> (1.0 ~ 1.75HP) or 4 × 2.5 mm<sup>2</sup> (2.0 ~ 2.5HP) flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short. Allowable connection cable length of each indoor unit shall be 30 m or less.
- 6 Bind all the indoor and outdoor connection cable with tape and route the connection cable via the right escapement.

7 Remove the tapes and connect the power supply cord and connection cable between indoor unit and outdoor unit according to the diagram below.




- 8 Secure the power supply cord and connection cable onto the control board with the holder.
- 9 Close grille door by tighten with screw and close the front panel.



Note:


- Isolating Devices (Disconnecting means) should have minimum 3.0 mm contact gap.
- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
- Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the anchorage.



# 11.3 Outdoor Unit

# 11.3.1 Install the Outdoor Unit

- After selecting the best location, start installation according to Indoor/Outdoor Unit Installation Diagram.
   1 Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut (ø10 mm).
  - 2 When installing at roof, please consider strong wind and earthquake.
  - Please fasten the installation stand firmly with bolt or nails.



Model	А	В	С	D	
RE9***,UE9***,YE9***	570 mm	105 mm	18.5 mm	320 mm	
UE12***,YE12***	570 1111	105 11111	10.5 1111		
RE12***					
RE15***	540 mm	160 mm	18.5 mm	330 mm	
UE18***					
RE18***	613 mm	131 mm	16 mm	360.5 mm	
RE24***	01311111	131 1111	10 11111	500.5 mm	

# **11.3.2** Connect the Piping

# 11.3.2.1 Connecting the Piping to Indoor

Please make flare after inserting flare nut (locate at joint portion, of tube assembly) onto the copper pipe. (In case of using long piping)

Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.


### 11.3.2.2 Connecting the Piping to Outdoor

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge.

Make flare after inserting the flare nut (located at valve) onto the copper pipe.


Align center of piping to valves and then tighten with torque wrench to the specified torque as stated in the table.

Do not overtighten, overtightening may cause gas leakage.					
Piping size Torque					
6.35 mm (1/4")	[18 N•m (1.8 kgf.m)]				
9.52 mm (3/8")	[42 N•m (4.3 kgf.m)]				
12.7 mm (1/2")	[55 N•m (5.6 kgf.m)]				
15.88 mm (5/8")	[65 N•m (6.6 kgf.m)]				
19.05 mm (3/4")	[100 N•m (10.2 kgf.m)]				



# 11.3.3 Evacuation of the Equipment

WHEN INSTALLING AN AIR CONDITIONER, BE SURE TO EVACUATE THE AIR INSIDE THE INDOOR UNIT AND PIPES in the following procedure.




- 1 Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve.
  - Be sure to connect the end of the charging hose with the push pin to the service port.
- 2 Connect the center hose of the charging set to a vacuum pump.
- 3 Turn on the power switch of the vacuum pump and make sure that the needle in the gauge moves from 0 cmHg (0 MPa) to -76 cmHg (-0.1 MPa). Then evacuate the air approximately ten minutes.
- 4 Close the Low side value of the charging set and turn off the vacuum pump. Make sure that the needle in the gauge does not move after approximately five minutes.
- Note: BE SURE TO TAKE THIS PROCEDURE IN ORDER TO AVOID REFRIGERENT GAS LEAKAGE.
- 5 Disconnect the charging hose from the vacuum pump and from the service port of the 3-way valve.
- 6 Tighten the service port caps of the 3-way valve at a torque of 18 N•m with a torque wrench.
- 7 Remove the valve caps of both of the 2-way valve and 3-way valve. Position both of the valves to "OPEN" using a hexagonal wrench (4 mm).
- 8 Mount valve caps onto the 2-way valve and the 3-way valve.
  - Be sure to check for gas leakage. .
- If gauge needle does not move from 0 cmHg (0 MPa) to -76 cmHg (-0.1 MPa), in the step ③ above take the following measure:
- If the leak stops when the piping connections are tightened further, continue working from step ③.
- If the leak does not stop when the connections are retightened, repair location of leak.
- Do not release refrigerant during piping work for installation and reinstallation.
- Take care of the liquid refrigerant, it may cause frostbite.

# 11.3.4 Connect the Cable to the Outdoor Unit

- 1 Remove the control board cover from the unit by loosening the screw.
- 2 Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 × 1.5 mm<sup>2</sup> (1.0 ~ 1.75HP) or 4 × 2.5 mm<sup>2</sup> (2.0 ~ 2.5HP) flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short. Allowable connection cable length of each indoor unit shall be 30 m or less.

Terminals on the outdoor unit	1	2	3	
Colour of wires				
Terminals on the indoor unit	1	2	3	

- 3 Secure the cable onto the control board with the holder (clamper).
- 4 Attach the control board cover back to the original position with screw.
- 5 For wire stripping and connection requirement, refer to instruction 11.2.4 of indoor unit.




• Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires for safety reason.


### 11.3.5 Piping Insulation

- 1 Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
- 2 If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 6 mm or above.

# 11.3.5.1 Cutting and flaring the piping

- 1 Please cut using pipe cutter and then remove the burrs.
- 2 Remove the burrs by using reamer. If burrs are not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- 3 Please make flare after inserting the flare nut onto the copper pipes.





When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.




# 12. Operation and Control

# 12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operation mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operation mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal setting temperature and intake air temperature.

### 12.1.1 Internal Setting Temperature

Once the operation starts, remote control setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the air conditioner settings and the operation environment. The final shifted value will be used as internal setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.



# 12.1.2 Cooling Operation

### 12.1.2.1 Thermostat control

- Compressor is OFF when Intake Air Temperature Internal Setting Temperature < -1.5°C continue for 3 minutes.
- When compressor is OFF (Thermostat OFF) and AUTO FAN is set the fan will stop periodically.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature Internal Setting Temperature > Compressor OFF point.

### 12.1.3 Soft Dry Operation

### 12.1.3.1 Thermostat control

- Compressor is OFF when Intake Air Temperature Internal Setting Temperature < -2.0°C continue for 3 minutes.
- When compressor is OFF (Thermostat OFF) and AUTO FAN is set the fan will stop periodically.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature Internal Setting Temperature > Compressor OFF point.


# 12.1.4 Heating Operation

### 12.1.4.1 Thermostat control

- Compressor is OFF when Intake Air Temperature Internal Setting Temperature > +2.0°C continued for 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature Internal Setting Temperature < Compressor OFF point.</li>


# 12.1.5 Automatic Operation

- This mode can be set using remote control and the operation is decided by remote control setting temperature, remote control operation mode and indoor intake air temperature.
- During operation mode judgment, indoor fan motor (with speed of Lo-) is running for 30 seconds to detect the indoor intake air temperature.
- Every 10 minutes, the indoor temperature is judged.
- For the 1st judgment
  - 1 If indoor intake temperature remote control setting temperature  $\geq 2^{\circ}C$ , COOL mode is decided.
  - 2 If -2°C ≤ indoor intake temperature remote control setting temperature < 2°C, DRY mode is decided.
  - 3 If indoor intake temperature remote control setting temperature <  $-2^{\circ}$ C, HEAT mode is decided.



#### • For the 2nd judgment onwards

- 1 If indoor intake temperature remote control setting temperature ≥ 3°C, if previous operate in DRY mode, then continue in DRY mode. otherwise COOL mode is decided.
- 2 If  $-2^{\circ}C \leq$  indoor intake temperature remote control setting temperature < 3°C, maintain with previous mode.
- 3 If indoor intake temperature remote control setting temperature < -2°C, HEAT mode is decided.



### 12.1.6 Indoor Fan Motor Operation

#### A. Basic Rotation Speed (rpm)

i. Manual Fan Speed

[Cooling, Dry]

• Fan motor's number of rotation is determined according to remote control setting.

Remote Control	0	0	0	0	0
Tab (rpm)	Hi	Me+	Me	Me-	Lo

#### [Heating]


• Fan motor's number of rotation is determined according to remote control setting.

Remote Control	0	0	0	0	0
Tab (rpm)	Shi	Me+	Me	Me-	Lo

ii. Auto Fan Speed

[Cooling, Dry]


- According to room temperature and setting temperature, indoor fan speed is determined automatically.
- When set temperature is not achieved, the indoor fan will operate according to pattern below.



• When set temperature achieved, the fan speed will be fixed.

[Heating]

• According to indoor pipe temperature, automatic heating fan speed is determined as follows.




#### **B. Feedback control**

- Immediately after the fan motor started, feedback control is performed once every second.
- During fan motor on, if fan motor feedback ≥ 2550 rpm or < 50 rpm continue for 10 seconds, then fan motor error counter increase, fan motor is then stop and restart. If the fan motor counter becomes 7 times, then H19 - fan motor error is detected. Operation stops and cannot on back.

# 12.1.7 Outdoor Fan Motor Operation

Outdoor fan motor is operated with one fan speed only. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



# 12.2 Airflow Direction


- 1 There are two types of airflow, vertical airflow (directed by horizontal vane) and horizontal airflow (directed by vertical vanes).
- 2 Control of airflow direction can be automatic (angles of direction is determined by operation mode, heat exchanger temperature and intake air temperature) and manual (angles of direction can be adjusted using remote control).

# 12.2.1 Vertical Airflow

	Operation Mode		Vane Angle (°)					
	Operation	INDUE	1	2	3	4	5	
	Auto Usual (Ventilation)				5 ~ 35			
Cooling	Auto	Control with dew		5 ~ 35				
Cooling	Manual	Usual (Ventilation)	5	12.5	20	27.5	35	
	Mariuai	Control with dew	5	12.5	20	27.5	35	
	Auto	Usual	5 ~ 35					
	Auto	Control with dew			5~35			
Dry	Manual	Usual	5	12.5	20	27.5	35	
Wanua	wallua	Control with dew	5	12.5	20	27.5	35	
Heating	Manual	Usual	5	17.5	30	42.5	55	

1 Automatic vertical airflow direction can be set using remote control; the vane swings up and down within the angles as stated above. For heating mode operation, the angle of the vane depends on the indoor heat exchanger temperature as Figure 1 below. It does not swing during fan motor stop. When the air conditioner is stopped using remote control, the vane will shift to close position.

2 Manual vertical airflow direction can be set using remote control; the angles of the vane are as stated above and the positions of the vane are as Figure 2 below. When the air conditioner is stopped using remote control, the vane will shift to close position.



#### **12.2.2 Horizontal Airflow**

1 Automatic horizontal airflow direction can be set using remote control; the vane swings left and right within the angles as stated below. It does not swing during fan motor stop. For heating mode operation, the angle of the vane depends on the indoor heat exchanger temperature as Figure 1 below.

Operation Mode			Vane Angle (°)
Heating with heat evaluations tomporature		А	68 ~ 115
Heating, with heat exchanger temperature		В	90
Cooling and Soft Dry			68 ~ 115
43°C A: swing B: fix front Indoor Heat Exchanger Temperature	0°	2	Top View 3 4 5
Figure 1			Figure 2

2 Manual horizontal airflow direction can be set using remote control; the angles of the vane are as stated below and the positions of the vane are as Figure 2 above.


Pattern	1	2	3	4	5
Airflow Direction Patterns at Remote Control					
Vane Angle (°)	90	70	80	100	110

# 12.3 ON Timer Control

ON timer can be set using remote control, the unit with timer set will start operate earlier than the setting time. This is to provide a comfortable environment when reaching the set ON time.

60 minutes before the set time, indoor (at fan speed of Lo-) and outdoor fan motor start operate for 30 seconds to determine the indoor intake air temperature and outdoor air temperature in order to judge the operation starting time.

From the above judgment, the decided operation will start operate earlier than the set time as shown below.



# 12.4 OFF Timer Control

OFF timer can be set using remote control, the unit with timer set will stop operate at set time.

# 12.5 Auto Restart Control

- 1 When the power supply is cut off during the operation of air conditioner, the compressor will re-operate within three to four minutes (there are 10 patterns between 2 minutes 58 seconds and 3 minutes 52 seconds to be selected randomly) after power supply resumes.
- 2 This type of control is not applicable during ON/OFF Timer setting.
- 3 This control can be omitted by short the circuit of JP1 at indoor unit printed circuit board.

# **13. Protection Control**

# 13.1 Protection Control For All Operations

# 13.1.1 Time Delay Safety Control


- $\circ$   $\;$  The compressor will not start for three minutes after stop of operation.
- This control is not applicable if the power supply is cut off and on again or after 4-way valve deices condition.

# 13.1.2 Total Running Current Control

- 1 When the outdoor unit total running current (AC) exceeds X value, the frequency instructed for compressor operation will be decreased.
- 2 If the running current does not exceed X value for five seconds, the frequency instructed will be increased.
- 3 However, if total outdoor unit running current exceeds Y value, compressor will be stopped immediately for three minutes.

Operation Mode	RE1	BQKE	RE24QKE		
Operation mode	X (A)	Y (A)	X (A)	Y (A)	
Cooling / Soft Dry (A)	11.73		14.52		
Cooling / Soft Dry (B)	8.82	14.67	12.31	19.04	
Cooling / Soft Dry (C)	8.82	14.07	12.31	19.04	
Heating	9.99		11.44		

4 The first 30 minutes of cooling operation, (A) will be applied.




# 13.1.3 IPM (Power transistor) Prevention Control

- Overheating Prevention Control
  - When the IPM temperature rises to 120°C (RE18QK) and 110°C (RE24QK), compressor operation will stop immediately.
  - Compressor operation restarts after three minutes the temperature decreases to 110°C (RE18QK) and 95°C (RE24QK).
  - o If this condition repeats continuously 4 times within 20 minutes, timer LED will be blinking ("F96" is indicated).
- DC Peak Current Control
  - When electric current to IPM exceeds set value of 30.0 ± 5.0 A, the compressor will stop operate. Then, operation will restart after three minutes.
  - If the set value is exceeded again more than 30 seconds after the compressor starts, the operation will restart after one minute.
  - If the set value is exceeded again within 30 seconds after the compressor starts, the operation will restart after one minute. If this condition repeats continuously for seven times, all indoor and outdoor relays will be cut off, timer LED will be blinking ("F99" is indicated).

# 13.1.4 Compressor Overheating Prevention Control

Instructed frequency for compressor operation will be regulated by compressor top temperature. The changes of frequency are as below figure.

If compressor discharge temperature exceeds 107°C (RE18QK) and 112°C (RE24QK), compressor will be stop, occurs 4 times per 20 minutes, timer LED will be blinking ("F97" is to be confirmed).



# 13.1.5 Low Pressure Prevention Control (Gas Leakage Detection)

- Control start conditions
  - For 5 minutes, the compressor continuously operates and outdoor total current is between 1.38A and 1.65A (RE18QK only).
  - For 5 minutes, the compressor continuously operates and outdoor total current is between 1.88A and 2.85A (Cooling), 2.85A and 3.57A (Heating) (RE24QK only).
  - During Cooling and Soft Dry operations:
    - Indoor suction temperature indoor piping temperature is below 4°C.
  - During Heating operations: Indoor piping temperature – indoor suction is under 5°C.
- Control contents
  - Compressor stops (and restart after 3 minutes).
  - o If the conditions above happen 2 times within 20 minutes, the unit will:
    - Stop operation
    - Timer LED blinks and "F91" indicated.

### 13.1.6 Low Frequency Protection Control 1

• When the compressor operate at frequency lower than 24 Hz (RE18QK) and 20 Hz (RE24QK) continued for 20 minutes, the operation frequency will be changed to 23 Hz (RE18QK) and 21 Hz (RE24QK) for 2 minutes.

# 13.1.7 Low Frequency Protection Control 2

• When all below conditions comply, the compressor frequency will change to lower frequency.

Temperature, T, for:	Cooling / Soft Dry	Heating
Indoor intake air (°C)	T < 14 or T ≥ 30	T < 14 or T ≥ 28
Outdoor air (°C)	T < 13 or T ≥ 38	T < 4 or T ≥ 24
Indoor heat exchanger (°C)	T < 30	T ≥ 0


# 13.2 Protection Control For Cooling & Soft Dry Operation

# 13.2.1 Outdoor Air Temperature Control

The compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.

This control will begin 1 minute after the compressor starts.

Compressor frequency will adjust base on Outdoor Air Temperature.



# 13.2.2 Cooling Overload Control

- Pipe temperature limitation / restriction (RE24QK only)
  - Detects the Outdoor pipe temperature and carry out below restriction/limitation (Limit the compressor Operation frequency)
  - The compressor stop if outdoor pipe temperature exceeds 63°C (RE18QK) and 65°C (RE24QK).
  - o If the compressor stops 4 times in 20 minutes, Timer LED blinking (F95: outdoor high pressure rise protection)

### 13.2.3 Dew Prevention Control

- 1 To prevent dew formation at indoor unit discharge area.
- 2 This control activated if:
  - Outdoor air temperature and Indoor pipe temperature judgment by microcontroller if fulfilled.
  - When Cooling or Dry mode is operated more than 20 minutes or more.
- 3 This control stopped if:
  - Compressor stopped.
  - o Remote control setting changed. (fan speed / temperature)
  - Outdoor air temperature and indoor intake temperature changed.
- 4 Fan speed will be adjusted accordingly in this control.

### 13.2.4 Freeze Prevention Control 1

- 1 When indoor heat exchanger temperature is lower than 0°C continuously for six minutes, compressor will stop operating.
- 2 Compressor will resume its operation three minutes after the indoor heat exchanger is higher than 5°C.
- 3 At the same time, indoor fan speed will be higher than during its normal operation.
- 4 If indoor heat exchanger temperature is higher than 5°C for five minutes, the fan speed will return to its normal operation.

### 13.2.5 Freeze Prevention Control 2

- 1 Control start conditions
  - During Cooling operation and soft dry operation
    - During thermo OFF condition, indoor intake temperature is less than 10°C or
    - Compressor stops for freeze prevention control
  - Either one of the conditions above occurs 5 times in 60 minutes.
- 2 Control contents

 $\cap$ 

0

- Operation stops.
- Timer LED blinks and "H99" indicated.

# 13.2.6 Odor Cut Control

- To reduce the odor released from the unit.
  - Start Condition
    - AUTO FAN Speed is selected during COOL or DRY operation.
    - During freeze prevention control and timer preliminary operation, this control is not applicable.
  - Control content
    - Depends on compressor conditions:
      - 1. Compressor OFF  $\rightarrow$  Compressor ON.
      - The indoor unit fan stops temporarily and then starts to blow at minimum airflow for 30 seconds. 2. Compressor  $ON \rightarrow Compressor OFF$ .
        - The indoor unit fan stops for 90 seconds and then blows at minimum airflow for 20 seconds.


# 13.3 Protection Control For Heating Operation

### 13.3.1 Intake Air Temperature Control

Compressor will operate at limited frequency if indoor intake air temperature is 30°C or above.


# 13.3.2 Outdoor Air Temperature Control

The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.



### 13.3.3 Overload Protection Control

- The compressor operating frequency is regulated in accordance to indoor heat exchanger temperature as shown in below figures.
- If the heat exchanger temperature exceeds 60°C, compressor will stop (RE18QK).



### 13.3.4 Cold Draught Prevention Control

When indoor pipe temperature is low, cold draught operation starts where indoor fan speed will be reduced.

### 13.3.5 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where indoor fan motor and outdoor fan motor stop and operation LED blinks.

# 14. Servicing Mode

# 14.1 Auto OFF/ON Button

ito OFF/ON Auto Of itton pressed Button p				)FF/ON pressed
<b>7</b>	5 sec	5	sec	
Auto Operation	Auto Operation Test Run Operation (Forced cooling operation)		Test Run Operation (Forced heating operation)	Stop
В	eep	Beep	x 2	

#### 1 AUTO OPERATION MODE

The Auto Operation will be activated immediately once the Auto OFF/ON button is pressed. This operation can be used to operate air conditioner with limited function if remote control is misplaced or malfunction.

#### 2 TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)

The Test Run operation will be activated if the Auto OFF/ON button is pressed continuously for more than 5 seconds. A "beep" sound will occur at the fifth seconds, in order to identify the starting of Test Run operation (Forced cooling operation). Within 5 minutes after Forced cooling operation start, the Auto OFF/ON button is pressed for more than 5 seconds. A 2 "beep" sounds will occur at the fifth seconds, in order to identify the starting of Forced heating operation.

The Auto OFF/ON button may be used together with remote control to set / change the advance setting of air conditioner operation.

to OFF/ON button pressed		Main unit always continue Test Run (forced cooling) operation						
	5 sec	8 sec		11 sec	16 sec			
Auto Operation		Operation ing Operation)	Test Run Operation (Forced Heating Operation)	Remote Control Number Switch Mode	Remote Control Receiving Sound OFF/ON			
	Веер	Веер	x 2	Beep x 3	Beep x 4			
				Press "AC RESET", then any key at remote control	Press "AC RESET" at remote control			

#### 3 REMOTE CONTROL NUMBER SWITCH MODE

The Remote Control Number Switch Mode will be activated if the Auto OFF/ON button is pressed continuously for more than 11 seconds (3 "beep" sounds will occur at 11th seconds to identify the Remote Control Number Switch Mode is in standby condition) and press "AC RESET" button and then press any button at remote control to transmit and store the desired transmission code to the EEPROM.

There are 4 types of remote control transmission code could be selected and stored in EEPROM of indoor unit. The indoor unit will only operate when received signal with same transmission code from remote control. This could prevent signal interference when there are 2 or more indoor units installed nearby together. To change remote control transmission code, short or open jumpers at the remote control printed circuit board.

	Remote Control Printed Circuit Board				
	Jumper A (D1)	Jumper B (D2)	Remote Control No.		
	Short with diode	Open	A (Default)		
	Open	Open	В		
	Short with diode	Short with diode	С		
D1	Open	Short with diode	D		

- \* Diode is field supplied. Part number: SOD-323 IN4148WS / LMDL914T1G
- During Remote Control Number Switch Mode, press any button at remote control to transmit and store the transmission code to the EEPROM.

4 REMOTE CONTROL RECEIVING SOUND OFF/ON MODE

The Remote Control Receiving Sound OFF/ON Mode will be activated if the Auto OFF/ON button is pressed continuously for more than 16 seconds (4 "beep" sounds will occur at 16th seconds to identify the Remote Control Receiving Sound Off/On Mode is in standby condition) and press "AC Reset" button at remote control.

Press "Auto OFF/ON button" to toggle remote control receiving sound.

- Short "beep": Turn OFF remote control receiving sound.
- Long "beep": Turn ON remote control receiving sound.

After Auto OFF/ON button is pressed, the 20 seconds counter for Remote Control Receiving Sound OFF/ON Mode is restarted.

# 14.2 Remote Control Button

### 14.2.1 SET BUTTON

- To check remote control transmission code and store the transmission code to EEPROM.
  - Press "SET" button for more than 10 seconds by using pointer.
  - Press "TIMER SET" button unit a "beep" sound is heard as confirmation of transmission code change.

### 14.2.2 RESET (RC)

To clear and restore the remote control setting to factory default
 Press once to clear the memory.

### 14.2.3 RESET (AC)

- To restore the unit's setting to factory default
  - Press once to restore the unit's setting.

### 14.2.4 TIMER ▲

To change indoor unit indicator's LED intensity
 Press continuously for 5 seconds.

#### 14.2.5 TIMER ▼

- To change remote control display from Degree Celsius to Degree Fahrenheit.
  - Press continuously for 10 seconds.

# 15. Troubleshooting Guide

# 15.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle. Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan. The normal outlet air temperature and pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.


Normal Pressure and Outlet Air Temperature (Standard)

	Gas pressure MPa (kg/cm²G)	Outlet air temperature (°C)
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)	12 ~ 16
Heating Mode	2.3 ~ 2.9 (23 ~ 29)	36 ~ 45

★ Condition: • Indoor fan speed; High

• Outdoor temperature 35°C at cooling

- mode and 7°C at heating mode.
- · Compressor operates at rated frequency



# 15.2 Relationship Between The Condition Of The Air Conditioner And Pressure And Electric Current

Condition of the		Cooling Mode		Heating Mode			
air conditioner	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation	
Insufficient refrigerant (gas leakage)	ĸ	ч	r	ч	ы	ч	
Clogged capillary tube or Strainer	И	ч	ч	7	7	7	
Short circuit in the indoor unit	ĸ	ч	r	7	7	Я	
Heat radiation deficiency of the outdoor unit	л	7	л	И	И	ч	
Inefficient compression	7	<i>د</i>	Я	Я	У	ч	

• Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

# 15.3 Breakdown Self Diagnosis Function

# 15.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- Once abnormality has occurred during operation, the unit will stop its operation, and Timer LEDs blink.
- Although Timer LED goes off when power supply is turned off, if the unit is operated under a breakdown condition, the LED will light up again.
- In operation after breakdown repair, the Timer LED will no more blink. The last error code (abnormality) will be stored in IC memory.

# 15.3.2 To Make a Diagnosis

- 1 Timer LED start to blink and the unit automatically stops the operation.
- 2 Press the CHECK button on the remote controller continuously for 5 seconds.
- 3 "- -" will be displayed on the remote controller display.
   Note: Display only for "- -". (No transmitting signal, no receiving sound and no Power LED blinking.)
- 4 Press the "TIMER" ▲ or ▼ button on the remote controller. The code "H00" (no abnormality) will be displayed and signal will be transmitted to the main unit.
- 5 Every press of the button (up or down) will increase abnormality numbers and transmit abnormality code signal to the main unit.
- 6 When the latest abnormality code on the main unit and code transmitted from the remote controller are matched, power LED will light up for 30 seconds and a beep sound (continuously for 4 seconds) will be heard. If no codes are matched, power LED will light up for 0.5 seconds and no sound will be heard.
- 7 The breakdown diagnosis mode will be canceled by pressing the CHECK button continuously for 5 seconds or without any operation the remote control for 30 seconds.
- 8 The LED will be off if the unit is turned off or the RESET button on the main unit is pressed.

# 15.3.3 To Display Memorized Error Code (Protective Operation) status:

- 1 Turn power on.
- 2 Press the CHECK button on the remote controller continuously for 5 seconds.
- 3 "--" will be displayed on the remote controller display.
   Note: Display only for "--". (No transmitting signal, no receiving sound and no Power LED blinking.)
- 4 Press the "TIMER" ▲ or ▼ button on the remote controller. The code "H00" (no abnormality) will be displayed and signal will be transmitted to the main unit. The power LED lights up. If no abnormality is stored in the memory, three beeps sound will be heard.
- 5 Every press of the button (up or down) will increase abnormality numbers and transmit abnormality code signal to the main unit.

- 6 When the latest abnormality code on the main unit and code transmitted from the remote controller are matched, power LED will light up for 30 seconds and a beep sound (continuously for 4 seconds) will be heard. If no codes are matched, power LED will light up for 0.5 seconds and no sound will be heard.
- 7 The breakdown diagnosis mode will be canceled unless pressing the CHECK button continuously for 5 seconds or operating the unit for 30 seconds.
- 8 The same diagnosis can be repeated by turning power on again.



# 15.3.4 To Clear Memorized Error (Protective Operation) Status after Repair:

- 1 Turn power on (in standby condition).
- 2 Press the AUTO button for 5 seconds (A beep receiving sound) on the main unit to operate the unit at Forced Cooling Operation mode.
- 3 Press the CHECK button on the remote controller for about 1 second with a pointed object to transmit signal to main unit. A beep sound is heard from main unit and the data is cleared.

# 15.3.5 Temporary Operation (Depending On Breakdown Status)

- 1 Press the AUTO button (A beep receiving sound) on the main unit to operate the unit. (Remote control will become possible.)
- 2 The unit can temporarily be used until repaired.

Error Code	Operation	Temporary items	
H23	Cooling	Emergency	
H27, H28	Cooling, Heating	Operation with	
H26	Cooling, Heating	limited power	

# 15.4 Error Codes Table

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Protection Operation	Problem	Check location
H00	No memory of failure	—	Normal operation	_	—
H11	Indoor/outdoor abnormal communication	After operation for 1 minute	Indoor fan only operation can start by entering into force cooling operation	Indoor/outdoor communication not establish	<ul> <li>Indoor/outdoor wire terminal</li> <li>Indoor/outdoor PCB</li> <li>Indoor/outdoor connection wire</li> </ul>
H12	Indoor unit capacity unmatched	90s after power supply	_	Total indoor capability more than maximum limit or less than minimum limit, or number of indoor unit less than two	<ul> <li>Indoor/outdoor connection wire</li> <li>Indoor/outdoor PCB</li> <li>Specification and combination table in catalogue</li> </ul>
H14	Indoor intake air temperature sensor abnormality	Continuous for 5s	_	Indoor intake air temperature sensor open or short circuit	Indoor intake air temperature sensor lead wire and connector
H15	Compressor temperature sensor abnormality	Continuous for 5s	_	Compressor temperature sensor open or short circuit	Compressor temperature     sensor lead wire and connector
H16	Outdoor current transformer (CT) abnormality	_	_	Current transformer faulty or compressor faulty	<ul> <li>Outdoor PCB faulty or compressor faulty</li> </ul>
H19	Indoor fan motor merchanism lock	Continuous happen for 7 times	—	Indoor fan motor lock or feedback abnormal	<ul> <li>Fan motor lead wire and connector</li> <li>Fan motor lock or block</li> </ul>
H23	Indoor heat exchanger temperature sensor abnormality	Continuous for 5s	_	Indoor heat exchanger temperature sensor open or short circuit	<ul> <li>Indoor heat exchanger temperature sensor lead wire and connector</li> </ul>
H24	Indoor heat exchanger temperature sensor 2 abnormality	Continuous for 5s	—	Indoor heat exchanger temperature sensor 2 open or short circuit	<ul> <li>Indoor heat exchanger temperature sensor 2 lead wire and connector</li> </ul>
H25	Indoor ion device abnormality	Port is ON for 10s during ion device off	—	_	ion device PCB
H27	Outdoor air temperature sensor abnormality	Continuous for 5s	_	Outdoor air temperature sensor open or short circuit	Outdoor air temperature sensor lead wire and connector
H28	Outdoor heat exchanger temperature sensor 1 abnormality	Continuous for 5s	_	Outdoor heat exchanger temperature sensor 1 open or short circuit	<ul> <li>Outdoor heat exchanger temperature sensor 1 lead wire and connector</li> </ul>
H30	Outdoor discharge pipe temperature sensor abnormality	Continuous for 5s	_	Outdoor discharge pipe temperature sensor open or short circuit	Outdoor discharge pipe temperature sensor lead wire and connector
H32	Outdoor heat exchanger temperature sensor 2 abnormality	Continuous for 5s	_	Outdoor heat exchanger temperature sensor 2 open or short circuit	Outdoor heat exchanger temperature sensor 2 lead wire and connector
H33	Indoor / outdoor misconnection abnormality	_	_	Indoor and outdoor rated voltage different	Indoor and outdoor units check
H34	Outdoor heat sink temperature sensor abnormality	Continuous for 2s	_	Outdoor heat sink temperature sensor open or short circuit	Outdoor heat sink sensor
H36	Outdoor gas pipe temperature sensor abnormality	Continuous for 5s	Heating protection operation only	Outdoor gas pipe temperature sensor open or short circuit	Outdoor gas pipe temperature sensor lead wire and connector
H37	Outdoor liquid pipe temperature sensor abnormality	Continuous for 5s	Cooling protection operation only	Outdoor liquid pipe temperature sensor open or short circuit	Outdoor liquid pipe temperature sensor lead wire and connector
H38	Indoor/Outdoor mismatch (brand code)	_		Brand code not match	Check indoor unit and outdoor unit
H39	Abnormal indoor operating unit or standby units	3 times happen within 40 minutes	_	Wrong wiring and connecting pipe, expansion valve abnormality, indoor heat exchanger sensor open circuit	<ul> <li>Check indoor/outdoor connection wire and connection pipe</li> <li>Indoor heat exchanger sensor lead wire and connector</li> <li>Expansion valve and lead wire and connector</li> </ul>

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Protection Operation	Problem	Check location
H41	Abnormal wiring or piping connection	_	_	Wrong wiring and connecting pipe, expansion valve abnormality	<ul> <li>Check indoor/outdoor connection wire and connection pipe</li> <li>Expansion valve and lead wire and connector</li> </ul>
H59	ECONAVI sensor abnormality	Continuous for 25s	_	ECONAVI sensor open or short circuit	<ul> <li>ECONAVI sensor (defective or disconnected)</li> <li>ECONAVI PCB</li> </ul>
H64	Outdoor high pressure sensor abnormality	Continuous for 1 minutes	_	High pressure sensor open circuit during compressor stop	<ul><li>High pressure sensor</li><li>Lead wire and connector</li></ul>
H70	Light sensor abnormality	Continuous for 24 hours, 15days		Light sensor open or short circuit	<ul> <li>Light sensor (defective or disconnected)</li> </ul>
H97	Outdoor fan motor mechanism lock	2 times happen within 30 minutes	_	Outdoor fan motor lock or feedback abnormal	<ul> <li>Outdoor fan motor lead wire and connector</li> <li>Fan motor lock or block</li> </ul>
H98	Indoor high pressure protection	_	_	Indoor high pressure protection (Heating)	<ul> <li>Check indoor heat exchanger</li> <li>Air filter dirty</li> <li>Air circulation short circuit</li> </ul>
H99	Indoor operating unit freeze protection		Ι	Indoor freeze protection (Cooling)	<ul> <li>Check indoor heat exchanger</li> <li>Air filter dirty</li> <li>Air circulation short circuit</li> </ul>
F11	4-way valve switching abnormality	4 times happen within 30 minutes	_	4-way valve switching abnormal	<ul><li> 4-way valve</li><li> Lead wire and connector</li></ul>
F17	Indoor standby units freezing abnormality	3 times happen within 40 minutes	_	Wrong wiring and connecting pipe, expansion valve leakage, indoor heat exchanger sensor open circuit	<ul> <li>Check indoor/outdoor connection wire and pipe</li> <li>Indoor heat exchanger sensor lead wire and connector</li> <li>Expansion valve lead wire and connector</li> </ul>
F90	Power factor correction (PFC) circuit protection	4 times happen within 10 minutes	_	Power factor correction circuit abnormal	Outdoor PCB faulty
F91	Refrigeration cycle abnormality	2 times happen within 20 minutes	_	Refrigeration cycle abnormal	Insufficient refrigerant or valve close
F93	Compressor abnormal revolution	4 times happen within 20 minutes		Compressor abnormal revolution	Power transistor module faulty or compressor lock
F94	Compressor discharge overshoot protection	4 times happen within 30 minutes	—	Compressor discharge pressure overshoot	Check refrigeration system
F95	Outdoor cooling high pressure protection	4 times happen within 20 minutes		Cooling high pressure protection	<ul><li>Check refrigeration system</li><li>Outdoor air circuit</li></ul>
F96	Power transistor module overheating protection	4 times happen within 30 minutes	_	Power transistor module overheat	<ul><li>PCB faulty</li><li>Outdoor air circuit (fan motor)</li></ul>
F97	Compressor overheating protection	3 times happen within 30 minutes	_	Compressor overheat	Insufficient refrigerant
F98	Total running current protection	3 times happen within 20 minutes	_	Total current protection	<ul> <li>Check refrigeration system</li> <li>Power source or compressor lock</li> </ul>
F99	Outdoor direct current (DC) peak detection	Continuous happen for 7 times	_	Power transistor module current protection	Power transistor module faulty     or compressor lock

# 15.5 Self-diagnosis Method


# 15.5.1 H11 (Indoor/Outdoor Abnormal Communication)

#### **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

#### **Malfunction Caused**

- Faulty indoor unit PCB.
- Faulty outdoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.




# 15.5.2 H12 (Indoor/Outdoor Capacity Rank Mismatched)

#### **Malfunction Decision Conditions**

• During startup, error code appears when different types of indoor and outdoor units are interconnected.

#### **Malfunction Caused**

- Wrong models interconnected.
- Wrong indoor unit or outdoor unit PCBs mounted.
- Indoor unit or outdoor unit PCBs defective.
- Indoor-outdoor unit signal transmission error due to wrong wiring.
- Indoor-outdoor unit signal transmission error due to breaking of wire 3 in the connection wires between the indoor and outdoor units.



#### 15.5.3 H14 (Indoor Intake Air Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**

During startup and operation of cooling and heating, the temperatures detected by the indoor intake air • temperature sensor are used to determine sensor errors.


#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.

#### Troubleshooting

40 30 20 10 0 -10 0 10 20 30 40 50

Temperature (°C)



# 15.5.4 H15 (Compressor Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**


• During startup and operation of cooling and heating, the temperatures detected by the outdoor compressor temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

• Faulty connector connection.

Temperature (°C)

- Faulty sensor.
- Faulty PCB.




# 15.5.5 H16 (Outdoor Current Transformer)

#### **Malfunction Decision Conditions**

• An input current, detected by Current Transformer CT, is below threshold value when the compressor is operating at certain frequency value for 3 minutes.

#### **Malfunction Caused**

- Lack of gas
- Broken CT (current transformer)
- Broken Outdoor PCB




# 15.5.6 H19 (Indoor Fan Motor – DC Motor Mechanism Locked)

#### **Malfunction Decision Conditions**

 The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550rpm or < 50rpm).</li>

#### **Malfunction Caused**

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation stops due to Hall IC malfunction.
- Operation error due to faulty indoor unit PCB.




# 15.5.7 H23 (Indoor Pipe Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**

 During startup and operation of cooling and heating, the temperatures detected by the indoor heat exchanger temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.8 H27 (Outdoor Air Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.9 H28 (Outdoor Pipe Temperature Sensor Abnormality)


#### **Malfunction Decision Conditions**

 During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.






# 15.5.10 H30 (Compressor Discharge Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.11 H32 (Outdoor Heat Exchanger Temperature Sensor 2 Abnormality)

#### **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the temperatures detected by the outdoor heat exchanger temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.12 H33 (Unspecified Voltage between Indoor and Outdoor)

#### **Malfunction Decision Conditions**

• The supply power is detected for its requirement by the indoor/outdoor transmission.

#### **Malfunction Caused**

- Wrong models interconnected.
- Wrong indoor unit and outdoor unit PCBs used.
- Indoor unit or outdoor unit PCB defective.




# 15.5.13 H34 (Outdoor Heat Sink Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the temperatures detected by the outdoor heat sink temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.14 H36 (Outdoor Gas Pipe Sensor Abnormality)

# **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the temperatures detected by the outdoor gas pipe temperature sensor are used to determine sensor errors.

# **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.15 H37 (Outdoor Liquid Pipe Temperature Sensor Abnormality)

#### **Malfunction Decision Conditions**

• During startup and operation of cooling and heating, the temperatures detected by the outdoor liquid pipe temperature sensor are used to determine sensor errors.

#### **Malfunction Caused**

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




# 15.5.16 H97 (Outdoor Fan Motor – DC Motor Mechanism Locked)

#### **Malfunction Decision Conditions**

• The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor.

#### **Malfunction Caused**

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation stops due to Hall IC malfunction.
- Operation error due to faulty outdoor unit PCB.




# 15.5.17 H98 (Error Code Stored in Memory and no alarm is triggered / no TIMER LED flashing)

#### **Malfunction Decision Conditions**

- Indoor high pressure is detected when indoor heat exchanger is detecting very high temperature when the unit is operating in heating operation.
- Phenomena: unit is stopping and re-starting very often in heating mode

#### **Malfunction Caused**

- Indoor heat exchanger thermistor
- Clogged air filter or heat exchanger
- Over-bent pipe (liquid side)



# 15.5.18 H99 (Indoor Freeze Prevention Protection: Cooling or Soft Dry)

## Error code will not display (no TIMER LED blinking) but store in EEPROM

#### **Malfunction Decision Conditions**

• Freeze prevention control takes place (when indoor pipe temperature is lower than 2°C).

#### **Malfunction Caused**

- Clogged air filter of the indoor unit.
- Dust accumulation on the indoor unit heat exchanger.
- Air short circuit.
- Detection error due to faulty indoor pipe temperature sensor.
- Detection error due to faulty indoor unit PCB.

When abnormality indication starts again	
Check the air passage	
▼ Is there any short circuit?	YES • Provide sufficient air passage
↓ NO Check the air filter	]
Is the air filter dirty?	YES ▶ Clean the air filter
NO Check the dust accumulation on the indoor unit heat exchanger	
Is the indoor unit heat exchanger dirty?	YES     Clean the indoor unit heat     exchanger
NO Check the indoor heat exchanger temperature sensor	
Does it conform to the sensor characteristic chart?	NO • Replace the indoor unit PCB
YES	<ul> <li>Defect in indoor unit PCB</li> <li>Replace the indoor unit PCB</li> </ul>

# 15.5.19 F11 (4-way valve Abnormality)


#### **Malfunction Decision Conditions**

 When indoor heat exchanger is cold during heating (except deice) or when indoor heat exchanger is hot during cooling and compressor operating, the 4-way valve is detected as malfunction.

#### **Malfunction Caused**

- Indoor heat exchanger (pipe) thermistor
- 4-way valve malfunction

### Troubleshooting



\* Check gas side pipe – for hot gas flow in cooling mode

# 15.5.20 F17 (Indoor Standby Units Freezing Abnormality)

#### **Malfunction Decision Conditions**


 When the different between indoor intake air temperature and indoor pipe temperature is above 10°C or indoor pipe temperature is below -1.0°C.

#### Remark:

When the indoor standby unit is freezing, the outdoor unit transfers F17 error code to the corresponding indoor unit and H39 to other indoor unit(s).

#### **Malfunction Caused**

- Wrong wiring connection
- Faulty sensor
- Faulty expansion valve




# 15.5.21 F90 (Power Factor Correction Protection)

# **Malfunction Decision Conditions**

- To maintain DC voltage level supply to power transistor.
- To detect high DC voltage level after rectification.

# Malfunction Caused

- During startup and operation of cooling and heating, when Power Factor Correction (PFC) protection circuitry at the outdoor unit main PCB senses abnormal DC voltage level for power transistors.
- When DC voltage detected is LOW, transistor switching will turn ON by controller to push-up the DC level.
- When DC voltage detected is HIGH (391Vdc 425Vdc), active LOW signal will send by the controller to turn OFF relay RY-C.




# 15.5.22 F91 (Refrigeration Cycle Abnormality)

#### **Malfunction Decision Conditions**

• The input current is low while the compressor is running at higher than the setting frequency.

#### **Malfunction Caused**

- Lack of gas.
- 3-way valve close.




# 15.5.23 F93 (Compressor Rotation Failure)

#### **Malfunction Decision Conditions**

A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

#### **Malfunction Caused**

- Compressor terminal disconnect.
- Outdoor PCB malfunction.




### 15.5.24 F95 (Outdoor High Pressure Protection: Cooling or Soft Dry)

#### **Malfunction Decision Conditions**

 During operation of cooling or soft dry, when outdoor unit heat exchanger high temperature data is detected by the outdoor unit heat exchanger thermistor.

#### **Malfunction Caused**

- Outdoor heat exchanger temperature rise due to short-circuit of hot discharge air flow.
- Outdoor heat exchanger temperature rise due to defective of outdoor fan motor.
- Outdoor heat exchange temperature rise due to defective outdoor heat exchanger thermistor.
- Outdoor heat exchanger temperature rise due to defective of outdoor unit PCB.



### 15.5.25 F96 (IPM Overheating)

### **Malfunction Decision Conditions**

 During operating of cooling and heating, when IPM temperature data (100°C) is detected by the IPM temperature sensor.

Multi Models Only

- o Compressor Overheating: During operation of cooling and heating, when the compressor OL is activated.
- Heat Sink Overheating: During operation of cooling and heating, when heat sink temperature data (90°C) is detected by the heat sink temperature sensor.

#### **Malfunction Caused**

- IPM overheats due to short circuit of hot discharge air flow.
- IPM overheats due to defective of outdoor fan motor.
- IPM overheats due to defective of internal circuitry of IPM.
- IPM overheats due to defective IPM temperature sensor.

Multi Models Only

- Compressor OL connector poor contact.
- Compressor OL faulty.

When F96 indication happens Check the outdoor unit installation condition (during cooling or soft-dry operation)	Caution	For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.
Is there any improper heat radiation?	J YES	<ul> <li>Reinstall the outdoor unit</li> <li>Remove the obstacle(s)</li> <li>Clean the outdoor heat exchanger</li> </ul>
NO		, i i i i i i i i i i i i i i i i i i i
Is outdoor fan motor operating?	NO	Replace the outdoor fan motor.
YES	-	
		<ul> <li>Defect in IPM</li> <li>Replace the outdoor unit PCB</li> </ul>


# 15.5.26 F97 (Compressor Overheating)

#### **Malfunction Decision Conditions**

During operation of cooling and heating, when compressor tank temperature data (112°C) is detected by the compressor tank temperature sensor.

#### **Malfunction Caused**

- Refrigerant shortage (refrigerant leakage).
- 2/3 way valve closed.
- Detection error due to faulty compressor tank temperature sensor.




# 15.5.27 F98 (Input Over Current Detection)

#### **Malfunction Decision Conditions**

During operation of cooling and heating, when an input over-current (X value in Total Running Current Control) is detected by checking the input current value being detected by current transformer (CT) with the compressor running.

#### **Malfunction Caused**

- Over-current due to compressor failure.
- Over-current due to defective outdoor unit PCB.
- Over-current due to defective inverter main circuit electrolytic capacitor.
- Over-current due to excessive refrigerant.




# 15.5.28 F99 (DC Peak Detection)

#### Malfunction Decision Conditions

During startup and operation of cooling and heating, when inverter DC peak data is received by the outdoor internal DC Peak sensing circuitry.

#### **Malfunction Caused**

- DC current peak due to compressor failure.
- DC current peak due to defective power transistor(s).
- DC current peak due to defective outdoor unit PCB.
- DC current peak due to short circuit.



- Checking the power transistor.
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidable necessary to touch a live part, make sure the power transistor's supply voltage is below 50V using the tester.
- For the UVW, make measurement at the Faston terminal on the board of the relay connector.


Tester's negative terminal	Power transistor (+)	UVW	Power transistor (-)	UVW				
Tester's positive terminal	UVW	Power transistor (+)	UVW	Power transistor (-)				
Normal resistance		Several kΩ to	o several MΩ					
Abnormal resistance	0 or ∞							

# 16. Disassembly and Assembly Instructions



# 16.1 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures

#### 16.1.1 To remove front grille



16.1.2 To remove horizontal vane




Figure 2

#### 16.1.3 To remove electronic controller




Figure 3

9. Detach AC303 (WHT) and RY-PWR (Black and Brown) wires from PCB, then detach AC304 (Red) wire from Terminal Board Complete.





Figure 4

# 16.1.4 To remove discharge grille



16.1.5 To remove control board






Figure 6

#### 16.1.6 To remove cross flow fan and indoor fan motor










Figure 10

# 16.2 Outdoor Electronic Controller Removal Procedure

#### 16.2.1 **CU-RE18QKE**

1 Remove the 8 screws of the Top Panel.





Fig. 1

2 Remove the 8 screws of the Front Panel.



3 Remove the Top Cover of the Electronic Controller.





Fig. 3

4 Remove the Control Board.



5 Remove the 6 screws of the Electronic Controller.




Fig. 5

A Caution! When handling electronic controller, be careful of electrostatic discharge.

# 16.2.2 CU-RE24QKE

1 Remove the 8 screws of the Top Panel.



2 Remove the 8 screws of the Front Panel.






Fig. 2

3 Remove the Top Cover of the Electronic Controller.



4 Remove the Control Board.



5 Remove the 6 screws of the Electronic Controller.




Fig. 5

▲ Caution! When handling electronic controller, be careful of electrostatic discharge.

# 17. Technical Data

Technical data provided are based on the air conditioner running under free frequency.

# 17.1 Cool Mode Performance Data

Unit setting: Standard piping length, Hi Fan, Cool mode at 16°C Voltage: 230V

### CS-RE18QKE/CU-RE18QKE

Indoo	or (°C)										Outd	oor DE	3 (°C)									
DB	WB	-10		-7		0		5		16			25			35						
DD	VVD	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	5707	4196	1028	5959	4294	938	5528	4143	1106	5716	4200	1019	5620	4200	1013	5229	3971	1273	5000	4040	1470
21	22.0	6546	3429	898	6270	3275	1014	6053	3254	1155	5853	3163	1071	6062	3341	1016	5686	3142	1287	5242	2398	1489
23	15.7	5022	4003	1134	5066	4062	1135	5179	4033	1047	5119	4023	1079	5211	4044	1013	4838	3886	1249	4347	3698	1552
23	18.4	5614	3228	1038	5379	3147	1143	6068	3376	911	5532	3063	1126	5688	3192	1015	5318	3024	1262	4785	2847	1580
20	13.3	4421	3794	1125	4205	3671	1242	4260	3685	829	4258	3704	921	4556	3849	848	4531	3844	1248	4008	3557	1525
20	15.8	4409	2845	1299	4679	2943	1176	4482	2853	862	5023	3158	791	6087	3551	1374	5430	3291	1602	4477	1581	1661

(Dry bulb value based on 46% humidity)

### CS-RE24QKE/CU-RE21QKE

Indoo	or (°C)										Outd	oor DE	8 (°C)									
DB	WB	-10		-7		0		5		16			25			35						
ЪВ	VVD	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	7761	5367	1468	8105	5493	1340	7519	5299	1580	7774	5373	1455	7644	5373	1447	7112	5079	1818	6800	5168	2100
21	22.0	8903	4387	1283	8528	4190	1448	8232	4163	1649	7961	4047	1529	8244	4274	1451	7733	4020	1838	7129	3067	2128
23	15.7	6830	5121	1620	6889	5196	1622	7043	5160	1495	6961	5146	1541	7088	5173	1447	6580	4970	1784	5912	4731	2217
23	18.4	7636	4129	1483	7316	4026	1633	8252	4319	1301	7523	3918	1609	7736	4083	1450	7233	3869	1803	6508	3642	2258
20	13.3	6012	4853	1607	5719	4696	1774	5794	4714	1184	5790	4738	1315	6196	4923	1211	6163	4918	1783	5451	4550	2179
20	15.8	5997	3640	1855	6364	3765	1680	6096	3650	1231	6831	4040	1129	8279	4542	1962	7385	4209	2288	6089	2023	2373

(Dry bulb value based on 46% humidity)

# 17.2 Heat Mode Performance Data

Unit setting: Standard piping length, Hi Fan, Heat mode at 30°C Voltage: 230V

# 17.2.1 CS- RE18QKE/CU-RE18QKE

Indoor (°C)		Outdoor WB (°C)									
DB	-10		-7		2		-	7	12		
DB	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP	
24	3497	1973	4717	2505	5431	2452	5368	1628	5908	1735	
20	3600	1901	4980	2410	5800	2350	5800	1540	6143	1665	
16	3362	1817	4772	2304	5569	2251	5647	1456	6308	1576	

# 17.2.2 CS- RE24QKE/CU-RE24QKE

Indoor (°C)		Outdoor WB (°C)									
DB	-10		-7		2		-	7	12		
00	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP	
24	4592	2276	5806	2858	6714	2890	7959	2759	8760	2940	
20	4727	2193	6130	2750	7170	2770	8600	2610	9109	2822	
16	4414	2096	5874	2629	6885	2653	8373	2467	9353	2672	

TC- Total Cooling Capacity (kW)SHC- Sensible Heat Capacity (kW)IP- Input Power (kW)


# 18. Service Data

Service data provided are based on the air conditioner running under rated frequency during forced cooling / forced heating mode.


# 18.1 Cool Mode Outdoor Air Temperature Characteristic

#### Condition

- Indoor room temperature: 27°C DryBulb/19°C Wet Bulb
- Unit setting: Standard piping length, forced cooling at 16°C, Hi fan
- Compressor frequency: Rated for cooling operation
- Voltage: 230V




### 18.1.1 CS/CU-RE18QKE



# 18.2 Heat Mode Outdoor Air Temperature Characteristic


Condition

- Indoor room temperature: 20°C DryBulb/ -°C Wet Bulb
- Unit setting: Standard piping length, forced heating at 30°C, Hi fan
- Compressor frequency: Rated for Heating operation
- Voltage: 230V



### 18.2.1 CS/CU-RE18QKE


# 18.2.2 CS/CU-RE24QKE



# 18.3 Piping Length Correction Factor

The characteristic of the unit has to be corrected in accordance with the piping length.


# 18.3.1 CS/CU-RE18QKE CS/CU-RE24QKE



Note: The graphs show the factor after added right amount of additional refrigerant.

# 19. Exploded View and Replacement Parts List

# 19.1 Indoor Unit



Note:

The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

#### <Model: CS-RE18QKE CS-RE24QKE

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-RE18QKE	CS-RE24QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD50C1654	←	
$\wedge$	2	FAN MOTOR	1	ARW7627AC	←	0
	3	CROSS-FLOW FAN COMPLETE	1	CWH02C1077	←	
	4	BEARING ASSY	1	CWH64K1010	←	
	5	SCREW - CROSS-FLOW FAN	1	CWH551146	<i>←</i>	
	7	EVAPORATOR	1	CWB30C4396	CWB30C4424	
	8	FLARE NUT (LIQUID)	1	CWT251030	<i>←</i>	
	9	FLARE NUT (GAS)	1	CWT251032	CWT251033	
	10	CLIP FOR SENSOR	2	CWH32143	←	
	11	CONTROL BOARD CASING	1	CWH102449	←	
$\wedge$	12	TERMINAL BOARD COMPLETE	1	CWA28C2365	←	0
$\overline{\mathbb{A}}$	13	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8116	CWA73C8117	0
$\overline{\mathbb{A}}$	15	ELECTRONIC CONTROLLER - INDICATOR	1	CWA746716	←	0
	16	SENSOR COMPLETE	1	CWA50C2663	<i>←</i>	0
	23	CONTROL BOARD TOP COVER	1	CWH131467	<i>←</i>	
	24	INDICATOR HOLDER	1	CWD933406	<i>←</i>	
	24a	INDICATOR HOLDER	1	CWD933496	<i>←</i>	
	25	CONTROL BOARD FRONT COVER CO.	1	CWH13C1247	←	
	26	DISCHARGE GRILLE COMPLETE	1	CWE20C3242	←	
	27	BACK COVER CHASSIS	1	CWD933031	←	
	28	FULCRUM	2	CWH621138	←	
	29	VERTICAL VANE	11	CWE241374	←	
	30	CONNECTING BAR	1	CWE261257	←	
	31	CONNECTING BAR	1	CWE261258	←	
$\land$	32	AIR SWING MOTOR	1	CWA98K1018		0
$\overline{\Lambda}$	33	AIR SWING MOTOR	1	CWA981241	←	0
<u> </u>	34	CAP - DRAIN TRAY	1	CWH521259	←	0
	35	HORIZONTAL VANE COMPLETE	1	CWE24C1392	←	
	36	REMOTE CONTROL COMPLETE	1	CWA75C4297		0
	37	FRONT GRILLE COMPLETE	1	CWE11C5833	CWE11C5834	0
	38		1	CWE22C1897	←	0
	39	GRILLE DOOR COMPLETE	1	CWE14C1090		
	40	AIR FILTER	2	CWD001283	←	0
	40	SCREW - FRONT GRILLE	3	XTT4+16CFJ	←	0
	41	CAP - FRONT GRILLE	3	CWH521227	←	
	42	DRAIN HOSE	1	CWH321227 CWH851173	←	
		INSTALLATION PLATE			→ 	
	44		1	CWH361098	← 	
	45	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C1705	← 	
	46		1	CWF569461	→ 	
	47		1	CWF569462	←	
	48		1	CWF616271	<i>←</i>	
	49	INSTALLATION INSTRUCTION	1	CWF616272	→	
	50	BAG	1	CWG861498	→	
	51	SHOCK ABSORBER ( L )	1	CWG713402	→ 	
	52	SHOCK ABSORBER ( R )	1	CWG713403		
	53	C.C.CASE	1	CWG567455	CWG567454	
	54	INSTALLATION INSTRUCTION	1	CWF616273	<i>←</i>	
	55	INSTALLATION INSTRUCTION	1	CWF616274	←	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-RE18QKE	CS-RE24QKE	REMARK
	56	INSTALLATION INSTRUCTION	1	CWF616275	←	
	57	INSTALLATION INSTRUCTION	1	CWF616276	←	
	58	INSTALLATION INSTRUCTION	1	CWF616277	←	
	59	INSTALLATION INSTRUCTION	1	CWF616278	←	
	60	INSTALLATION INSTRUCTION	1	CWF616279	←	
	61	INSTALLATION INSTRUCTION	1	CWF616280	←	
	62	ANTI-BACTERIAL FILTER	1	CWD00C1280	←	


(Note)

All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock. •

•

# 19.2 Outdoor Unit

19.2.1 CU-RE18QKE



Note:


The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service part.

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-RE18QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD52K1261	
	2	ANTI - VIBRATION BUSHING	3	CWH50077	
$\wedge$	3	COMPRESSOR	1	5RD132XBA21	0
	4	NUT - COMPRESSOR MOUNT	3	CWH56000J	
	5	SOUND PROOF MATERIAL	1	CWG302632	
	6	FAN MOTOR BRACKET	1	CWD541153	
$\wedge$	7	FAN MOTOR	1	ARW8401AC	0
	8	SCREW - FAN MOTOR BRACKET	2	CWH551217	
	9	SCREW - FAN MOTOR MOUNT	4	CWH551106J	
	10	PROPELLER FAN ASSY	1	CWH03K1065	
	11	NUT - PROPELLER FAN	1	CWH56053J	
	12	CONDENSER	1	CWB32C3764	
	14	EXPANSION VALVE	1	CWB051016J	0
	15	4-WAYS VALVE	1	CWB001026J	0
	18	HOLDER COUPLING	1	CWH351227	
	19	3-WAY VALVE (GAS)	1	CWB011338	0
	20	2-WAYS VALVE (LIQUID)	1	CWB021454	0
	22	SOUND PROOF BOARD	1	CWH151257	
	23	TERMINAL COVER	1	CWH171039A	
	24	NUT - TERMINAL COVER	1	CWH7080300J	
$\triangle$	27	V-COIL COMPLETE (FOR 4 WAY VALVE)	1	CWA43C2169J	0
$\overline{\mathbb{A}}$	28	V-COIL COMPLETE (FOR EXPANSION VALVE)	1	CWA43C2257	0
	29	SENSOR CO - COMP. TEMP	1	CWA50C2185	0
	30	SENSOR - COMPLETE	1	CWA50C2517	0
$\wedge$	31	REACTOR	1	G0C203J00003	0
$\overline{\mathbb{A}}$	33	TERMINAL BOARD ASSY	1	CWA28K1036J	0
$\overline{\mathbb{A}}$	38	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8127R	0
	40	CONTROL BOARD COVER - TOP	1	CWH131333	
	41	CABINET SIDE PLATE CO. (LEFT)	1	CWE041560A	
	42	HANDLE	1	CWE161010	
	43	CABINET SIDE PLATE (RIGHT)	1	CWE041798A	
	45	CABINET FRONT PLATE CO.	1	CWE06K1077	
	47	CABINET TOP PLATE	1	CWE031083A	
	48	CONTROL BOARD COVER - COMPLETE	1	CWH13C1238	
	49	CONTROL BOARD COVER	1	CWH131409A	
	58	SOUND PROOF MATERIAL	1	CWG302636	
	59	SOUND PROOF MATERIAL	1	CWG302630	
	60	STRAINER	1	CWB11094	
	62	RECEIVER	1	CWB14011	
	63	SOUND PROOF MATERIAL	1	CWG302744	
	64	BAG - COMPLETE	1	CWG87C900	
	65	BAG	1	CWG861461	
	66	BASE BOARD - COMPLETE	1	CWG62C1131	
	67	SHOCK ABSORBER (LEFT)	1	CWG713217	
	68	SHOCK ABSORBER (RIGHT)	1	CWG713218	
	69	C.C.CASE	1	CWG568360	

(Note)

•

All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock. •



Note:

The above exploded view is for the purpose of parts disassembly and replacement.

The non-numbered parts are not kept as standard service part.

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-RE24QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD52K1190	
	2	ANTI - VIBRATION BUSHING	3	CWH50055	
	3	PACKING	3	CWB81043	
$\wedge$	4	COMPRESSOR	1	5KD240XAF21	0
	5	NUT - COMPRESSOR MOUNT	3	CWH561049	
	9	FAN MOTOR BRACKET	1	CWD541127	
$\triangle$	10	FAN MOTOR	1	EHDS80C60AC	0
	11	SCREW - FAN MOTOR BRACKET	2	CWH551217	
	12	SCREW - FAN MOTOR MOUNT	4	CWH551323	
	13	PROPELLER FAN ASSY	1	CWH00K1006	
	14	NUT - PROPELLER FAN	1	CWH561092	
	15	CONDENSER	1	CWB32C3706	
	16	TUBE ASSY CO.(CAP TUBE)	1	CWT01C5849	
	17	DISCHARGE MUFFLER	1	CWB121013	
	18	EXPANSION VALVE	1	CWB051018J	0
	22	4-WAYS VALVE	1	CWB001026J	0
	24	HOLDER COUPLING	1	CWH351228	
	25	3-WAY VALVE (GAS)	1	CWB011363	0
	26	2-WAYS VALVE (LIQUID)	1	CWB021434	0
	27	SOUND PROOF BOARD	1	CWH151197	
	28	TERMINAL COVER	1	CWH171039A	
	29	NUT - TERMINAL COVER	1	CWH7080300J	
	30	SENSOR CO - COMP. TEMP	1	CWA50C2185	0
$\wedge$	31	V-COIL COMPLETE (FOR 4 WAY VALVE)	1	CWA43C2169J	0
$\overline{\mathbb{A}}$	32	V-COIL COMPLETE (FOR EXPANSION VALVE)	1	CWA43C2258	0
<u>~~</u>	35	SENSOR - COMPLETE	1	CWA50C2517	0
$\wedge$	36	REACTOR	2	G0C403J00001	0
<u>~~</u>	37	CONTROL BOARD COVER	1	CWH131332	
$\triangle$	38	TERMINAL BOARD ASSY	1	CWA28K1036J	0
$\Delta$	40	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8124R	0
<u>~~</u>	41	CONTROL BOARD COVER - TOP	1	CWH131333	
	42	CABINET SIDE PLATE CO. (LEFT)	1	CWE041585A	
	43	HANDLE	1	CWE161010	
	44	CABINET SIDE PLATE (RIGHT)	1	CWE041799A	
	44	CABINET FRONT PLATE (NGTT)	1	CWE06K1063	
	40	CABINET TOP PLATE	1	CWE031083A	
	49	CONTROL BOARD COVER - COMPLETE	1	CWH13C1185	
	49 50	STRAINER	2	CWB111032	
	51		1	CWB14017	
	53	SOUND PROOF MATERIAL	1	CWG302245	
A	54		1	CWG302246	
$\triangle$	56	ELECTRONIC CONTROLLER - NF	1	CWA747379	
	57	BAG - COMPLETE	1	CWG87C900	
	58	BAG	1	CWG861154	
	59	BASE BOARD-COMPLETE	1	CWG62C1081	
	60	SHOCK ABSORBER (RIGHT)	1	CWG712879	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-RE24QKE	REMARK
	61	SHOCK ABSORBER (LEFT)	1	CWG712880	
	62	C.C.CASE	1	CWG568361	

(Note)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.