Air conditioner

User manual

AJ***TNNDKG

- Thank you for purchasing this Samsung air conditioner.
- Before operating this unit, please read this user manual carefully and retain it for future reference.

SAMSUNG

Contents

Safety Information	3
Safety Information	3
At a Glance	11
Indoor Unit Overview	11
Operation Features	12
Operating temperature and humidity	
Cleaning and Maintenance	13
Cleaning and Maintaining	13
Cleaning the indoor unit exterior • Cleaning the outdoor unit heat exchanger	
Cleaning the air filter • Periodical maintenance • Troubleshooting	
Information about refrigerant	19
Important information: regulation regarding the refrigerant used	



Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

For information on Samsung's environmental commitments and product-specific regulatory obligations, e.g. REACH, visit: https://www.samsung.com/uk/sustainability/environment/environment-data/

Before using your new air conditioner, please read this manual thoroughly to ensure that you know how to safely and efficiently operate the extensive features and functions of your new appliance.

Because the following operating instructions cover various models, the characteristics of your air conditioner may differ slightly from those described in this manual. If you have any questions, call your nearest contact centre or find help and information online at www.samsung.com.



Hazards or unsafe practices that may result in severe personal injury or death.

⚠ CAUTION

Hazards or unsafe practices that may result in minor personal injury or property damage.

- Follow directions.
- O Do NOT attempt.
- Make sure the machine is grounded to prevent electric shock.
- Cut-off the power supply.
- Do NOT disassemble.



WARNING: Low burning velocity material (This appliance is filled with R-32.)



The user and installer guides should be read carefully.



The user and installer guides should be read carefully.



The service guide should be read carefully.

FOR INSTALLATION

⚠ WARNING

- Use the power line with the power specifications of the product or higher and use the power line for this appliance only. In addition, do not use an extension line.
 - Extending the power line may result in electric shock or fire.
 - Do not use an electric transformer. This may result in electric shock or fire.
 - If the voltage/frequency/rated current condition is different, it may cause

The installation of this appliance must be performed by a qualified technician or service company.

• Failing to do so may result in electric shock, fire, explosion, problems with the product, or injury and may also void warranty on the installed product.

Install a switch and circuit breaker dedicated to the air conditioner.

• Failing to do so may result in electric shock or fire.

Fix the outdoor unit firmly so that the electric part of the outdoor unit is not exposed.

- Failing to do so may result in electric shock or fire, explosion, or problems with the product.
- O Do not install this appliance near a heater, inflammable material. Do not install this appliance in a humid, oily or dusty location, in a location exposed to direct sunlight and water (rain drops). Do not install this appliance in a location where gas may leak.
 - This may result in electric shock or fire.

Never install the outdoor unit in a location such as on a high external wall where it could fall.

- If the outdoor unit falls, it may result in injury, death or property damage.
- This appliance must be properly grounded. Do not ground the appliance to a gas pipe, plastic water pipe, or telephone line.
 - Failure to do so may result in electric shock, fire, an explosion, or other problems with the product.

• Never plug the power cord into a socket that is not grounded correctly and make sure that it is in accordance with local and national codes.

⚠ CAUTION

- Install your appliance on a level and hard floor that can support its weight.
 - Failing to do so may result in abnormal vibrations, noise, or problems with the product.

Install the drain hose properly so that water is drained correctly.

• Failing to do so may result in water overflowing and property damage. Avoid adding drain to waste pipes as odours may arise in the future.

The product shall be stored in a room with no ignition sources (e.g. open flames, gas appliance, electric heater, etc.).

• Note that the refrigerant has no odour.

When installing the outdoor unit, make sure to connect the drain hose so that draining is performed correctly.

 The water generated during the heating operation in the outdoor unit may overflow and result in property damage.
 In particular, in winter, if a block of ice falls, it may result in injury, death or property damage.

Do not install the product in a place where thermo-hygrostat is needed (such as server room, machinery room, computer room, etc.)

• Those places do not provide guaranteed operation condition of the product therefore performance can be poor in these places.

FOR POWER SUPPLY

⚠ WARNING

- When the circuit breaker is damaged, contact your nearest service centre.
- On not pull or excessively bend the power line. Do not twist or tie the power line. Do not hook the power line over a metal object, place a heavy object on the power line, insert the power line between objects, or push the power line into the space behind the appliance.
 - This may result in electric shock or fire.

⚠ CAUTION



When not using the air conditioner for a long period of time or during a thunder/lightning storm, cut the power at the circuit breaker.

• Failing to do so may result in electric shock or fire.

FOR USING



⚠ WARNING



• If the appliance is flooded, please contact your nearest service centre.

• Failing to do so may result in electric shock or fire.

If the appliance generates a strange noise, a burning smell or smoke, unplug the power plug immediately and contact your nearest service centre.

Failing to do so may result in electric shock or fire.

In case of a malfunction, immediately stop operation of the air conditioner and disconnect the entire power system. Then consult the authorized service personnel.

In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power line. Do not touch the appliance or power line.

- Do not use a ventilating fan.
- A spark may result in an explosion or fire.

To reinstall the air conditioner, please contact your nearest service centre.

- Failing to do so may result in problems with the product, water leakage. electric shock, or fire.
- A delivery service for the product is not provided. If you reinstall the product in another location, additional construction expenses and an installation fee will be charged.
- Especially, when you wish to install the product in an unusual location such as in an industrial area or near the seaside where it is exposed to salt in the air, please contact your nearest service centre.
- Do not touch the circuit breaker with wet hands.
 - This may result in electric shock.

- O not turn the air conditioner off with the circuit breaker while it is operating.
 - Turning the air conditioner off and then on again with the circuit breaker may cause a spark and result in electric shock or fire.

After unpacking the air conditioner, keep all packaging materials well out of the reach of children, as packaging materials can be dangerous to children.

• If a child places a bag over its head, it may result in suffocation.

Do not touch the front panel with your hands or fingers during the heating operation.

• This may result in electric shock or burns.

Do not insert your fingers or foreign substances into the outlet when the air conditioner is operating or the front panel is closing.

• Take special care that children do not injure themselves by inserting their fingers into the product.

Do not insert your fingers or foreign substances into the air inlet/outlet of the air conditioner.

• Take special care that children do not injure themselves by inserting their fingers into the product.

Do not strike or pull the air conditioner with excessive force.

• This may result in fire, injury, or problems with the product.

Do not place an object near the outdoor unit that allows children to climb onto the machine.

• This may result in children seriously injuring themselves.

Do not use this air conditioner for long periods of time in badly ventilated locations or near infirm people.

• Since this may be dangerous due to a lack of oxygen, open a window at least once an hour.

Do not use means to accelerate the defrost operation or to clean, other than those recommended by Samsung.

Do not pierce or burn.

Be aware that refrigerants may not contain an odour.

- If any foreign substance such as water has entered the appliance, cut the power by unplugging the power plug and turning the circuit breaker off and then contact your nearest service centre.
 - Failing to do so may result in electric shock or fire.
- Do not attempt to repair, disassemble, or modify the appliance yourself.
 - Do not use any fuse (such as copper, steel wire, etc.)other than the standard fuse.
 - Failing to do so may result in electric shock, fire, problems with the product, or injury.

⚠ CAUTION

- **①** Do not place objects or devices under the indoor unit.
 - Water dripping from the indoor unit may result in fire or property damage.

Check that the installation frame of the outdoor unit is not broken at least once a year.

• Failing to do so may result in injury, death or property damage.

Max current is measured according to IEC standard for safety and current is measured according to ISO standard for energy efficiency.

When the air conditioner does not operate properly for cooling or heating, there is a possibility of refrigerant leakage. If any leakage, stop operation, ventilate the room, and consult your dealer immediately for recharging refrigerant.

The refrigerant is not harmful. However, if it comes in contact with fire, it may generate harmful gases and there is risk of fire.

During transportation of the indoor unit, the pipe lines shall be covered with brackets for protection. Do not move the product with holding the pipe lines.

• It may cause gas leakage.

Do not install the product in a ship or a vehicle (such as a campervan).

- Salt, vibration or other environmental factor may cause the product malfunction, electric shock or fire.
- On not stand on top of the appliance or place objects (such as laundry, lighted candles, lighted cigarettes, dishes, chemicals, metal objects, etc.) on the appliance.
 - This may result in electric shock, fire, problems with the product, or injury.

- O not operate the appliance with wet hands.
 - This may result in electric shock.

Do not spray volatile material such as insecticide onto the surface of the appliance.

• As well as being harmful to humans, it may also result in electric shock, fire or problems with the product.

Do not drink the water from the air conditioner.

• The water may be harmful to humans.

Do not apply a strong impact to the remote controller and do not disassemble the remote controller.

Do not touch the pipes connected with the product.

• This may result in burns or injury.

Do not cut or burn the refrigerant container or pipings.

Do not point the air direction to the fireplace or heater.

Do not use this air conditioner to preserve precision equipment, food, animals, plants or cosmetics, or for any other unusual purposes.

• This may result in property damage.

Avoid directly exposing humans, animals or plants to the air flow from the air conditioner for long periods of time.

• This may result in harm to humans, animals or plants.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

For use in Europe: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

FOR CLEANING

⚠ WARNING

- O not clean the appliance by spraying water directly onto it. Do not use benzene, thinner, alcohol or acetone to clean the appliance.
 - This may result in discoloration, deformation, damage, electric shock or fire.

Before cleaning or performing maintenance, unplug the air conditioner from the wall socket and wait until the fan stops.


• Failing to do so may result in electric shock or fire.

! CAUTION


- Take care when cleaning the surface of the heat exchanger of the outdoor unit since it has sharp edges.
 - To avoid cutting your fingers, wear thick cotton gloves when cleaning it.
 - This should be done by a qualified technician please contact your installer or service centre.
- O not clean the inside of the air conditioner by yourself.
 - For cleaning inside the appliance, contact your nearest service centre.
 - When cleaning the internal filter, refer to the descriptions in the 'Cleaning and Maintaining' section.
 - Failure to do may result in damage, electric shock or fire.
 - Make sure to prevent any injury from sharp edges of the surface when handling the heat exchanger.

Indoor Unit Overview

The indoor unit and its display may look slightly different from the illustration shown below, depending on the model and the panel type.



01 Display



O2 Air flow blade/Air outlet (inside) / Wind-Free panel (You can use the Wind-Free Cooling function when the Cool, Dry, or Fan mode is running.) (Refer to the remote control manual for product operation.)

- **03** Airintake
- **04** Air filter (under the grille)

Indication	Function	
Ů	On/Off operation indicator	
*	Removing frost indicator	
(1)	Timer indicator	
	Filter cleaning indicator	
\bigcirc	Remote control sensor	

Operation Features

Operating temperature and humidity

When using the air conditioner follow the operating temperature and humidity ranges.


Mode	Outdoor temperature	Indoor temperature	Indoor humidity	If out of conditions
Cool mode	Depending	16°C to 32°C	80% or less	Condensation may occur on the indoor unit with risk to have either water blow off or drop on the floor.
Heat mode	on the outdoor unit specifications	27°C or less	-	Internal protection triggers and the air conditioner will stop.
Dry mode		18°C to 32°C	-	Condensation may occur on the indoor unit with risk to have either water blow off or drop on the floor.

↑ CAUTION

- If you use the air conditioner at a relative humidity above 80%, it may cause a formation of condensation and a leakage of water on the floor.
- The standardized temperature for heating is 7°C. If the outdoor temperature drops to 0°C or below, the heating capacity can be reduced depending on the temperature condition. If the cooling operation is used at over 32°C (indoor temperature), it does not cool at its full capacity.
- If the indoor unit is out of the operating temperature and humidity range, the safety device may operate and the air conditioner may stops.

Before cleaning the indoor unit, be sure to turn off the auxiliary power switch.

Cleaning the indoor unit exterior




Wipe the surface of the unit with a slightly wet or dry cloth when needed. Wipe off dirt of oddshaped areas by using a soft brush.

A CAUTION

- Do not use alkaline detergent, sulphuric acid, hydrochloric acid, or organic solvents (such as thinner, kerosene, and acetone) to clean the surfaces.
- Do not attach any stickers on the surfaces because this may cause damage.
- When you clean the heat exchanger on the indoor unit, you need to disassemble the indoor unit. Therefore, you must contact the local service center for help.

Cleaning the outdoor unit heat exchanger



! CAUTION

• The heat exchanger of the outdoor unit has sharp edges. Take care when cleaning its surface.


NOTE

 If it is difficult to clean the heat exchanger of the outdoor unit, contact the local service center

Cleaning the air filter

A CAUTION


- Be sure to hold the grille with a hand to prevent dropping from the opening of the front grille.
- 1 Detaching the air filter



Push down the hooks at each side of the front grille to open the grille.


NOTE

• The hooks are located on both sides of the front grill with the Samsung logo.



Pull out the air filter from the indoor unit


2 Cleaning the air filter



Clean the air filter with a vacuum cleaner or soft brush. If dust is too heavy, then rinse it with running water and dry it in a ventilated area.

⚠ CAUTION


Do not scrub the air filter with a brush or other cleaning utensil. This may damage the filter.



NOTE


- If the air filter dries in a humid area, it may produce offensive odours. Clean it again and dry it in a well-ventilated area.
- The cleaning period may differ depending on the usage and environmental conditions, so clean the air filter every week if the indoor unit is in the dusty area.

3 Reassembling the air filter



↑ CAUTION

• If the indoor unit is used without the air filter, the indoor unit may be damaged due to dust.



4 Resetting the air filter (Wired remote control is an optional item)

After cleaning and reassembling the air filter, be sure to reset the filter-cleaning reminder as follows:

- Indoor unit with the wired remote control: Press the **Filter Reset** button or set **Filter Reset** in option.
- Indoor unit with the wireless remote control: Press the **Options** button → ⟨ or ⟩ → (**Filter Reset**) Blinking → press the **SET** button.

NOTE

- The filter reset indicator blinks when the air filter should be cleaned.
- If the angle of the air flow blade is changed by opening the front grille for installation or maintenance of the indoor unit, be sure to turn off and then on the auxiliary switch before operating the indoor unit again. If not, the angle of the air flow blade may be changed and the blades may not be closed after turning off the indoor unit.

Periodical maintenance

Unit	Maintenance item	Interval	Requires qualified technicians
	Clean the air filter.	At least once a month	
	Clean the condensate drain pan.	Once a year	Required
Indoor unit	Clean up the heat exchange.	Once a year	Required
diffe	Clean the condensate drain pipe.	Once every 4 months	Required
	Replace the remote control batteries.	At least once a year	
	Clean the heat exchanger on the outside of the unit.	Once every 4 months	Required
Outdoor unit	Clean the heat exchanger on the inside of the unit.	Once a year	Required
	Clean the electric components with jets of air.	Once a year	Required
	Verify that all the electric components are firmly tightened.	Once a year	Required
	Clean the fan.	Once a year	Required
	Verify that the fan assemblies are firmly tightened.	Once a year	Required
	Clean the condensate drain pan.	Once a year	Required

Troubleshooting

Refer to the following chart if the air conditioner operates abnormally. This may save time and unnecessary expense.

Problem	Solution	
The air conditioner does not operate immediately after it has been restarted.	Because of the protective mechanism, the appliance does not start operating immediately to keep the unit from overloading. The air conditioner will start in 3 minutes.	
The air conditioner does not work at all.	 Check power status and then operate the air conditioner again. Check if the circuit breaker is switched off. Check if there is a power failure. Check your fuse. Make sure it is not blown out. 	
The temperature does not change.	Check if you selected Fan mode. Press the Mode button on the remote control to select another mode.	
The cool (warm) air does not come out of the air conditioner.	 Check if the set temperature is higher (lower) than the current temperature. Press the Temperature button on the remote control to change the set temperature. Press the Temperature button to decrease or increase the temperature. Check if the air filter is blocked by dirt. Clean the air filter every two weeks. Check if the air conditioner has just been turned on. If so, wait 3 minutes. Cool air does not come out to protect the compressor of the outdoor unit. Check if the air conditioner is installed in a place with a direct exposure to sunlight. Hang curtains on windows to boost cooling efficiency. Check if the cover or any obstacle is not near the outdoor unit. Check if the refrigerant pipe is too long. Check if the remote control is only available in Cool mode. Check if the remote control is only available for cooling model. 	
The fan speed does not change.	 Check if you selected Auto or Dry mode. The air conditioner automatically adjusts the fan speed to Auto in Auto/ Dry mode. 	
Timer function does not set.	Check if you press the Power button on the remote control after you have set the time.	
Odors permeate in the room during operation.	Check if the appliance is running in a smoky area or if there is a smell entering from outside. Operate the air conditioner in Fan mode or open the windows to air out the room.	

Problem	Solution
The air conditioner makes a bubbling sound.	 A bubbling sound may be heard when the refrigerant is circulating through the compressor. Let the air conditioner operate in a selected mode. When you press the Power button on the remote control, noise may be heard from the drain pump inside the air conditioner.
Water is dripping from the air flow blades.	Check if the air conditioner has been cooling for an extended period of time with the air flow blades pointed downwards. Condensation may generate due to the difference in temperature.
Remote control is not working.	 Check if your batteries are depleted. Make sure batteries are correctly installed. Make sure nothing is blocking your remote control sensor. Check that there are strong lighting apparatus near the air conditioner. Strong light which comes from fluorescent bulbs or neon signs may interrupt the electric waves.
The air conditioner does not turn on or off with the wired remote control.	Check if you set the wired remote control for group control.
The wired remote control does not operate.	Check if TEST indicator is displayed on the wired remote control. If so, turn off the unit and switch off the circuit breaker. Call your nearest contact center.
The indicators of the digital display flashes.	Press the Power button on the remote control to turn the unit off and switch the circuit breaker off. Then, switch it on again.

Information about refrigerant

Important information: regulation regarding the refrigerant used

This product contains fluorinated greenhouse gases. Do not vent gases into the atmosphere.

⚠ CAUTION

If the system contains 5 $\rm tCO_2e$ or more of fluorinated greenhouse gases, it must be checked for leakage at least once every 12 months, according to regulation No. 517/2014. This activity must be covered by qualified personnel only. In the case of the situation above, the installer (or authorized person with responsibility for final check) must provide a maintenance book, with all the information recorded, according to REGULATION (EU) No. 517/2014 OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL of 16 April 2014 on fluorinated greenhouse gases.

Refrigenat type	GWP value
R-32	675

• GWP: Global Warming Potential

• Calculating tCO₂e: kg x GWP/1000

SAMSUNG

QUESTIONS OR COMMENTS?

NORWAY 21629099 www.samsung.com/fo/support	COUNTRY	CALL	OR VISIT US ONLINE AT
GERMANY	UK	0333 000 0333	www.samsung.com/uk/support
FRANCE	IRELAND (EIRE)	0818 717100	www.samsung.com/ie/support
ITALIA	GERMANY	06196 77 555 77	www.samsung.com/de/support
SPAIN	FRANCE	01 48 63 00 00	www.samsung.com/fr/support
PORTUGAL Chamada para a refe fix nacional Dias (teis das 9h às 20h Dias (at a teis das 9h às 20h Dias (at a	ITALIA	800-SAMSUNG (800.7267864)	www.samsung.com/it/support
PORTUGAL Chamada para a rede fixa nacional Dias úteis das 9h às 20h www.samsung.com/pt/support LUXEMBURG 26103710 www.samsung.com/be_frt/support NETHERLANDS 088 90 90 100 www.samsung.com/be_fsupport (Dutch) BELGIUM 02-201-24-18 www.samsung.com/be_fsupport (Dutch) NORWAY 21629099 www.samsung.com/be_fsupport (French NORWAY 21629099 www.samsung.com/fs/support DENMARK 707 019 70 www.samsung.com/fs/support FINLAND 030-6227 515 www.samsung.com/fs/support SWEDEN 0771-400 300 www.samsung.com/fs/support PULAND 801-172-678* lub +48 22 607-93-33+ http://www.samsung.com/fs/support HUNGARY 0680SAMSUNG (0800-726-7864) www.samsung.com/pl/support/ AUSTRIA 0800 72 678 64 (0800-5AMSUNG) www.samsung.com/fs/support SWITZERLAND 0800 726 786 www.samsung.com/fs/support (German) SUCAKIA 0800 - SAMSUNG (0800-726 786) www.samsung.com/fs/support SLOVAKIA 0800 - SAMSUNG (0800-726 786) www.samsung.com/fs/support NOTH Macedonia 025 233 599 www.samsung.com	SPAIN	91 175 00 15	www.samsung.com/es/support
NETHERLANDS 088 90 90 100 www.samsung.com/lo/support (Dutch) BELGIUM 02-201-24-18 www.samsung.com/be_str/support (Dutch) NORWAY 21629099 www.samsung.com/be_ft/support (French DENMARK 707 019 70 www.samsung.com/dk/support FINLAND 030-6227 515 www.samsung.com/ft/support SWEDEN 0771-400 300 www.samsung.com/ft/support POLAND 801-172-678* lub +48 22 607-93-33* http://www.samsung.com/pl/support HUNGARY 06805AMSUNG (0680-726-7864) www.samsung.com/pl/support HUNGARY 06805AMSUNG (0680-726-7864) www.samsung.com/pl/support AUSTRIA 0800 72 67 864 (0800-58MSUNG) www.samsung.com/rk/support SWITZERLAND 0800 726 786 www.samsung.com/ch_fr/support (German) CZECH 800 - SAMSUNG (800-726786) www.samsung.com/ch_fr/support (German) LOVAKIA 0800 - SAMSUNG (0800-726786) www.samsung.com/sk/support CROATIA 072 726 786 www.samsung.com/sk/support North Macedonia 052 323 977 www.samsung.com/sk/support North Macedonia 023 20 7777 www.samsung.com/sk/support	PORTUGAL	Chamada para a rede fixa nacional	www.samsung.com/pt/support
BELGIUM 02-201-24-18	LUXEMBURG	261 03 710	www.samsung.com/be_fr/support
BELGIOM U2-2U1-24-18 www.samsung.com/be_fr/support (French NORWAY 21629099 www.samsung.com/no/support DENMARK 707 019 70 www.samsung.com/fl/support FINLAND 030-6227 515 www.samsung.com/fl/support SWEDEN 0771-400 300 www.samsung.com/se/support POLAND 801-172-678* lub +48 22 607-93-33* http://www.samsung.com/pl/support/ HUNGARY 06805AMSUNG (0680-726-7864) www.samsung.com/hu/support AUSTRIA 0800 72 67 864 (0800-SAMSUNG) www.samsung.com/hu/support SWITZERLAND 0800 726 786 www.samsung.com/hu/support CZECH 800 - SAMSUNG (800-726786) www.samsung.com/hc_fr/support (French SLOVAKIA 0800 - SAMSUNG (800-726786) www.samsung.com/hc_fr/support (French CROATIA 072 726 786 www.samsung.com/hr/support NOTTE Macedonia 023 207 777 www.samsung.com/hr/support MONTENEGRO 020 405 888 www.samsung.com/support SEOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/si/support	NETHERLANDS	088 90 90 100	www.samsung.com/nl/support
DENMARK 707 019 70 www.samsung.com/dk/support FINLAND 030-6227 515 www.samsung.com/fi/support SWEDEN 0771-400 300 www.samsung.com/se/support POLAND 801-172-678* lub +48 22 607-93-33* * (optata wedtug taryfy operatora) http://www.samsung.com/pl/support/ HUNGARY 0680SAMSUNG (0680-726-7864) www.samsung.com/hu/support AUSTRIA 0800 72 67 864 (0800-SAMSUNG) www.samsung.com/ch/support (Fernan) SWITZERLAND 0800 72 67 86 www.samsung.com/ch/support (Fernan) CZECH 800 - SAMSUNG (800-726786) www.samsung.com/ch/support (French CZECH 800 - SAMSUNG (0800-726 786) www.samsung.com/sk/support CROATIA 072 726 786 www.samsung.com/sk/support BOSNIA 055 233 999 www.samsung.com/sk/support North Macedonia 023 207 777 www.samsung.com/sk/support MONTENEGRO 020 405 888 www.samsung.com/si/support SERBIA 011 321 6899 www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/si/support BULGARIA 0800 111 31 - Безnamen за всички оператори www.samsung.	BELGIUM	02-201-24-18	www.samsung.com/be/support (Dutch) www.samsung.com/be_fr/support (French)
FINLAND	NORWAY	21629099	www.samsung.com/no/support
SWEDEN 0771-400 300 www.samsung.com/se/support POLAND 801-172-678* lub +48 22 607-93-33* http://www.samsung.com/pl/support/ 90 peratora) http://www.samsung.com/pl/support/ http://www.samsung.com/pl/support HUNGARY 0680SAMSUNG (0680-726-7864) www.samsung.com/at/support AUSTRIA 0800 72 67 864 (0800-SAMSUNG) www.samsung.com/ch_fr/support (German) www.samsung.com/ch_fr/support (French 2004) CZECH 800 - SAMSUNG (800-726786) www.samsung.com/cz/support SLOVAKIA 0800 - SAMSUNG (0800-726786) www.samsung.com/cz/support GRATIA 072 726 786 www.samsung.com/fr/support BOSNIA 055 233 999 www.samsung.com/sk/support North Macedonia 023 207 777 www.samsung.com/support MONTENEGRO 020 405 888 www.samsung.com/support SLOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/si/support ALBANIA 045 620 20 2 www.samsung.com/sl/support BULGARIA 0800 111 31 - Безплатен за Всички оператор парифарат на мобильния погратор парифарат на мобильния погратор парифарат на мобильния погратор парифарат на мобильния погратор парифарат на мобильния по	DENMARK	707 019 70	www.samsung.com/dk/support
POLAND 801-172-678* lub +48 22 607-93-33*	FINLAND	030-6227 515	www.samsung.com/fi/support
# (opłata według taryfy operatora) # (opłata wew.samsung.com/hu/support operatory) # (opłata według taryfy operatora) # (opłata wew.samsung.com/chy/support operatory) # (opłata wew.samsung.com/support operatory) # (opłata wew.samsung.com/support operatory) # (opłata wew.samsung.com/chy/support operatory) # (opłata wew.samsu	SWEDEN	0771-400 300	www.samsung.com/se/support
AUSTRIA 0800 72 67 864 (0800-SAMSUNG) www.samsung.com/at/support SWITZERLAND 0800 726 786 www.samsung.com/ch_fr/support (French CZECH 800 - SAMSUNG (800-726786) www.samsung.com/cb_support (French SLOVAKIA 0800 - SAMSUNG (0800-726786) www.samsung.com/cs/support CROATIA 072 726 786 www.samsung.com/sk/support BOSNIA 055 233 999 www.samsung.com/hr/support North Macedonia 023 207 777 www.samsung.com/mk/support MONTENEGRO 020 405 888 www.samsung.com/si/support SLOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/support SERBIA 011 321 6899 www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/si/support ALBANIA 045 620 202 www.samsung.com/si/support BULGARIA 0800 111 31 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 go 18:00 - Понеделник до Петьк 0800872678 - Apel gratuit *8000 - Apel tarifat in retea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS 8009 4000 only from landline, toll free 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support	POLAND		http://www.samsung.com/pl/support/
SWITZERLAND 0800 726 786 www.samsung.com/ch_fr/support (German) www.samsung.com/ch_fr/support (French CZECH 800 - SAMSUNG (800-726786) www.samsung.com/ch_fr/support (French Flow, proft (French SLOVAKIA) 0800 - SAMSUNG (0800-726 786) www.samsung.com/cz/support CROATIA 072 726 786 www.samsung.com/sk/support www.samsung.com/hr/support BOSNIA 055 233 999 www.samsung.com/ba/support North Macedonia 023 207 777 www.samsung.com/ba/support MONTENEGRO 020 405 888 www.samsung.com/support SLOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/support SERBIA 011 321 6899 www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/si/support ALBANIA 045 620 202 www.samsung.com/sl/support BULGARIA 0800 1113 1 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор www.samsung.com/sl/support ROMANIA 0800 2000 - Понеделник до Петтък www.samsung.com/ro/support ROMANIA 0800872678 - Apel gratuit *8000 - 1000 engle formation in the program Call Center www.samsung.com/ro/support CYPRUS 80	HUNGARY	0680SAMSUNG (0680-726-7864)	www.samsung.com/hu/support
SWITZERLAND CZECH 800 - SAMSUNG (800-726786) SLOVAKIA 0800 - SAMSUNG (0800-726786) Www.samsung.com/cz/support CROATIA 072 726 786 Www.samsung.com/sk/support BOSNIA 055 233 999 Www.samsung.com/bs/support Www.samsung.com/bs/support Www.samsung.com/mk/support Www.samsung.com/mk/support Www.samsung.com/s/support Www.samsung.com/support Www.samsung.com/si/support SLOVENIA 080 697 267 (brezplačna številka) SERBIA 011 321 6899 Www.samsung.com/si/support KOSOVO 038 40 30 90 Www.samsung.com/si/support #3000 - Llena ha eguh apagoku pagao8op unu cnopeg mapuфama ha мобилният onepamop 09:00 go 18:00 - Понеделник go Петък #8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS 8009 4000 only from landline, toll free BOSNIA Www.samsung.com/ro/support Www.samsung.com/ro/support Www.samsung.com/gr/support Www.samsung.com/gr/support Www.samsung.com/gr/support Www.samsung.com/gr/support Www.samsung.com/gr/support Www.samsung.com/gr/support Www.samsung.com/gr/support Www.samsung.com/lt/support Www.samsung.com/lt/support Www.samsung.com/lt/support	AUSTRIA	0800 72 67 864 (0800-SAMSUNG)	www.samsung.com/at/support
SLOVAKIA 0800 - SAMSUNG (0800-726 786) www.samsung.com/sk/support CROATIA 072 726 786 www.samsung.com/hr/support BOSNIA 055 233 999 www.samsung.com/ba/support North Macedonia 023 207 777 www.samsung.com/support MONTENEGRO 020 405 888 www.samsung.com/si/support SLOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/support SERBIA 011 321 6899 www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/support ALBANIA 045 620 202 www.samsung.com/sl/support BULGARIA 0800 111 31 - Безплатен за Всички оператор тарифата на мобилният оператор О9:00 go 18:00 - Понеделник до Петък www.samsung.com/bg/support ROMANIA 88000 - Ареl tarifat în rețea Program Call Center Luri - Vineri: 9 AM - 6 PM www.samsung.com/ro/support CYPRUS 8009 4000 only from landline, toll free www.samsung.com/gr/support GREECE 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line www.samsung.com/lt/support LITHUANIA 8-800-77777 www.samsung.com/lt/support	SWITZERLAND	0800 726 786	www.samsung.com/ch/support (German) www.samsung.com/ch_fr/support (French)
CROATIA 072 726 786 www.samsung.com/hr/support BOSNIA 055 233 999 www.samsung.com/ba/support North Macedonia 023 207 777 www.samsung.com/support MONTENEGRO 020 405 888 www.samsung.com/support SLOVENIA 080 697 267 (brezplačna številka) www.samsung.com/si/support SERBIA 011 321 6899 www.samsung.com/si/support KOSOVO 038 40 30 90 www.samsung.com/si/support ALBANIA 045 620 202 www.samsung.com/support BULGARIA 0800 111 31 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 go 18:00 - Понеделник до Петьк ROMANIA 8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS 8009 4000 only from landline, toll free GREECE 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support Www.samsung.com/lt/support www.samsung.com/lt/support	CZECH	800 - SAMSUNG (800-726786)	www.samsung.com/cz/support
BOSNIA055 233 999www.samsung.com/ba/supportNorth Macedonia023 207 777www.samsung.com/mk/supportMONTENEGRO020 405 888www.samsung.com/supportSLOVENIA080 697 267 (brezplačna številka)www.samsung.com/si/supportSERBIA011 321 6899www.samsung.com/rs/supportKOSOVO038 40 30 90www.samsung.com/supportALBANIA045 620 202www.samsung.com/supportBULGARIA0800 111 31 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 go 18:00 - Понеделник go Петькwww.samsung.com/bg/supportROMANIA*8000 - Apel tarifat în reţea 	SLOVAKIA	0800 - SAMSUNG (0800-726 786)	www.samsung.com/sk/support
North Macedonia023 207 777www.samsung.com/mk/supportMONTENEGRO020 405 888www.samsung.com/supportSLOVENIA080 697 267 (brezplačna številka)www.samsung.com/si/supportSERBIA011 321 6899www.samsung.com/rs/supportKOSOVO038 40 30 90www.samsung.com/supportALBANIA045 620 202www.samsung.com/supportBULGARIA0800 111 31 - Безллатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 до 18:00 - Понеделник до Петъкwww.samsung.com/bg/supportROMANIA0800872678 - Apel gratuit *8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PMwww.samsung.com/ro/supportCYPRUS8009 4000 only from landline, toll freewww.samsung.com/ro/supportGREECE80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land linewww.samsung.com/lt/supportLITHUANIA8-800-77777www.samsung.com/lt/supportLATVIA8000-7267www.samsung.com/lt/support	CROATIA	072 726 786	www.samsung.com/hr/support
MONTENEGRO020 405 888www.samsung.com/supportSLOVENIA080 697 267 (brezplačna številka)www.samsung.com/si/supportSERBIA011 321 6899www.samsung.com/rs/supportKOSOVO038 40 30 90www.samsung.com/supportALBANIA045 620 202www.samsung.com/supportBULGARIA0800 111 31 - Безплатен за всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 go 18:00 - Понеделник до Петъкwww.samsung.com/bg/supportROMANIA0800872678 - Apel gratuit *8000 - Apel tarifat în rețea Program Call Center Luni - Vineri: 9 AM - 6 PMwww.samsung.com/ro/supportCYPRUS8009 4000 only from landline, toll freewww.samsung.com/ro/supportGREECE80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land linewww.samsung.com/gr/supportLITHUANIA8-800-77777www.samsung.com/lt/supportLATVIA8000-7267www.samsung.com/lt/support	BOSNIA	055 233 999	www.samsung.com/ba/support
SLOVENIA080 697 267 (brezplačna številka)www.samsung.com/si/supportSERBIA011 321 6899www.samsung.com/rs/supportKOSOVO038 40 30 90www.samsung.com/supportALBANIA045 620 202www.samsung.com/al/supportBULGARIA0800 111 31 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 go 18:00 - Понеделник до Петькwww.samsung.com/bg/supportROMANIA0800872678 - Apel gratuit *8000 - Apel tarifat în rețea Program Call Center Luni - Vineri: 9 AM - 6 PMwww.samsung.com/ro/supportCYPRUS8009 4000 only from landline, toll freewww.samsung.com/gr/supportGREECE80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land linewww.samsung.com/gr/supportLITHUANIA8-800-77777www.samsung.com/lt/supportLATVIA8000-7267www.samsung.com/lt/support	North Macedonia	023 207 777	www.samsung.com/mk/support
SERBIA O11 321 6899 Www.samsung.com/rs/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/support Www.samsung.com/bg/support #3000 - Lleha на един градски разговор или според марифата на мобилният оператор O9:00 до 18:00 - Понеделник до Петьк Www.samsung.com/bg/support #8000 - Apel tarifat în rețea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS #8009 4000 only from landline, toll free GREECE #80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA #8-800-77777 Www.samsung.com/lt/support www.samsung.com/lt/support Www.samsung.com/lt/support	MONTENEGRO	020 405 888	www.samsung.com/support
KOSOVO038 40 30 90www.samsung.com/supportALBANIA045 620 202www.samsung.com/al/supportBULGARIA0800 111 31 - Безллатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 до 18:00 - Понеделник до Петъкwww.samsung.com/bg/supportROMANIA0800872678 - Apel gratuit *8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PMwww.samsung.com/ro/supportCYPRUS8009 4000 only from landline, toll freewww.samsung.com/gr/supportGREECE80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land linewww.samsung.com/gr/supportLITHUANIA8-800-77777www.samsung.com/lt/supportLATVIA8000-7267www.samsung.com/lt/support	SLOVENIA	080 697 267 (brezplačna številka)	www.samsung.com/si/support
ALBANIA 045 620 202 www.samsung.com/al/support 0800 111 31 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 до 18:00 - Понеделник до Петък 0800872678 - Ареl gratuit *8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS 8009 4000 only from landline, toll free GREECE 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support www.samsung.com/lt/support www.samsung.com/lt/support	SERBIA	011 321 6899	www.samsung.com/rs/support
BULGARIA 0800 111 31 - Безплатен за Всички оператори *3000 - Цена на един градски разговор или според тарифата на мобилният оператор 09:00 до 18:00 - Понеделник до Петък 0800872678 - Ареl gratuit *8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS 8009 4000 only from landline, toll free GREECE 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support www.samsung.com/lt/support www.samsung.com/lt/support	KOSOVO	038 40 30 90	www.samsung.com/support
BULGARIA *3000 - Цена на един градски разговор или според марифама на мобилниям операмор 09:00 до 18:00 - Понеделник до Петък ROMANIA *0800872678 - Apel gratuit *8000 - Apel tarifat în reţea Program Call Center Luni - Vineri: 9 АМ - 6 РМ CYPRUS 8009 4000 only from landline, toll free 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support www.samsung.com/lt/support 1211140140 8000-7267 www.samsung.com/lt/support	ALBANIA	045 620 202	www.samsung.com/al/support
ROMANIA *8000 - Apel tarifat în rețea Program Call Center Luni - Vineri: 9 AM - 6 PM CYPRUS 8009 4000 only from landline, toll free GREECE 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support LATVIA 8000-7267 www.samsung.com/lv/support	BULGARIA	*3000 - Цена на един градски разговор или според тарифата на мобилният оператор	www.samsung.com/bg/support
GREECE 80111-SAMSUNG (80111 726 7864) only from land line (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support LATVIA 8000-7267 www.samsung.com/lv/support	ROMANIA	*8000 - Apel tarifat În rețea Program Call Center Luni - Vineri: 9 AM - 6 PM	www.samsung.com/ro/support
GREECE (+30) 210 6897691 from mobile and land line LITHUANIA 8-800-77777 www.samsung.com/lt/support LATVIA 8000-7267 www.samsung.com/lv/support	CYPRUS	8009 4000 only from landline, toll free	
LATVIA 8000-7267 www.samsung.com/lv/support	GREECE		www.samsung.com/gr/support
LATVIA 8000-7267 www.samsung.com/lv/support	LITHUANIA	8-800-77777	www.samsung.com/lt/support
3 11			
	ESTONIA	800-7267	www.samsung.com/ee/support